



Table



Cisco HyperFlex Series 4.5 Systems HX Series Common Criteria Security Target

Version: 3.0

Date: 22 December 2021

Cisco Systems, Inc.

All printed copies and duplicate soft copies are considered un-Controlled copies and the original on-line version should be referred to for latest version.

© 2021Cisco Systems, Inc. All rights reserved.

Table of Contents

1.	Security Target Introduction.....	7
1.1	ST and TOE Reference.....	7
1.2	TOE Overview	8
1.3	TOE Product Type.....	13
1.3.1	Required non-TOE Hardware/Software/Firmware	14
1.4	TOE Description	15
1.5	TOE Evaluated Configuration	19
1.6	Physical Scope of the TOE.....	20
1.6.1	TOE Documentation	30
1.7	Logical Scope of the TOE.....	31
1.1.1	Security Audit.....	31
1.7.1	User Data Protection.....	31
1.7.2	Identification and Authentication.....	32
1.7.3	Security Management	32
1.7.4	Protection of the TSF	32
1.7.5	Resource Utilization.....	33
1.7.6	TOE Access.....	33
1.7.7	Trusted Path/Channels.....	33
1.8	Excluded Functionality.....	33
2.	Conformance Claims.....	33
2.1	Common Criteria Conformance Claim	33
2.2	Protection Profile Conformance Claim	34
3.	Security Problem Definition.....	34
3.1	Assumptions.....	34
3.2	Threats	34
3.3	Organizational Security Policies.....	35
4.	Security Objectives.....	36

4.1	Security Objectives for the TOE	36
4.2	Security Objectives for the Environment.....	36
5.	Security Requirements	37
5.1	Conventions.....	37
5.2	TOE Security Functional Requirements.....	38
5.3	Security Functional Requirements	39
5.3.1	Class: Security Audit (FAU)	39
5.3.1.1	FAU_GEN.1 – Audit Data Generation	39
5.3.1.2	FAU_GEN.2 – User Identity Association	40
5.3.1.3	FAU_SAR.1 –Audit Review	40
5.3.1.4	FAU_STG.1 – Protected Audit Event Storage	40
5.3.2	Class: User Data Protection (FDP)	41
5.3.2.1	FDP_ACC.2 Complete access control	41
5.3.2.2	FDP_ACF.1 Security attribute based access control	41
5.3.3	Class: Identification and Authentication (FIA)	41
5.3.3.1	FIA_ATD.1 User attribute definition	41
5.3.3.2	FIA_SOS.1 Verification of secrets	42
5.3.3.3	FIA_UAU.2 – User authentication before any action	42
5.3.3.4	FIA_UAU.7 – Protected Authentication Feedback	42
5.3.3.5	FIA_UID.2 – X.509 Certificate Validation	42
5.3.4	Class: Security Management (FMT)	42
5.3.4.1	FMT_MSA.1 – Management of security attributes	42
5.3.4.2	FMT_MSA.3 –Static attribute initialization	42
5.3.4.3	FMT_MTD.1– Management of TSF Data	42
5.3.4.4	FMT_SMF.1 – Specification of Management Functions	42
5.3.4.5	FMT_SMR.1 –Security Roles	43
5.3.5	Class: Protection of the TSF (FPT)	43
5.3.5.1	FPT_FLS.1 – Failure with preservation of secure state	43
5.3.5.2	FPT_STM.1 – Reliable time stamps	43
5.3.6	Resource Utilisation (FRU)	43
5.3.6.1	FRU_FLT.2 Limited Fault Tolerance	43
5.3.7	Class: TOE Access (FTA).....	43
5.3.7.1	FTA_SSL.3 – TSF-initiated Termination	43
5.3.8	Class: Trusted Path (FTP).....	43
5.3.8.1	FTP_TRP.1 – Trusted Path	43
5.4	TOE SFR Dependencies Rationale	44
5.5	Security Assurance Requirements.....	45

5.5.1	SAR Requirements	45
5.5.2	Security Assurance Requirements Rationale.....	46
5.6	Assurance Measures.....	46
6.	TOE Summary Specification	48
6.1	TOE Security Functional Requirement Measures	48
6.2	TOE Bypass and interference/logical tampering Protection Measures.....	51
7.	Rationale.....	52
7.1	Rationale for TOE Security Objectives.....	52
7.2	Rationale for TOE Security Objectives for the Environment	53
7.3	Rationale for requirements /TOE Objectives	55
8.	Annex A: References.....	59
9.	Annex B: Acronyms.....	60
10.	Annex C – Terminology.....	62
11.	Annex D: Obtaining Documentation and Submitting a Service Request	65
12.	Contacting Cisco	65

Table of Tables

Table 1	ST and TOE Identification	7
Table 2	IT Environment Component.....	14
Table 3	Hardware Models and Description	20
Table 4	Excluded Functionality and Rationale	33
Table 5	TOE Assumptions	34
Table 6	Threats	35
Table 7	Security Objectives for the TOE	36
Table 8	Security Objectives for the Environment.....	37
Table 9	Security Requirement Conventions	37
Table 10	Security Functional Requirements	38
Table 11	Auditable Events	39
Table 12	SFR Dependency Rationale	44
Table 13	SAR Requirements.....	45
Table 14	Assurance Measures	46
Table 15	How TOE SFRs Measures.....	48

Table 16 Threats & IT Security Objectives Mapping.....	52
Table 17 TOE Threat/Policy/Objective Rationale	53
Table 18 Threats & IT Security Objectives Mappings for the Environment.....	54
Table 19 Assumptions/Threats/Objectives Rationale	54
Table 20 Security Objective to Security Requirements Mappings	55
Table 21 Objectives to Requirements Rationale	56
Table 22 References.....	59
Table 23 Acronyms	60
Table 24 Terms.....	62

Table of Figures

Figure 1 Cisco HyperFlex Standard Cluster Topology	9
Figure 2 Cisco HyperFlex Extended Cluster Topology.....	10
Figure 3 Cisco HyperFlex Stretched Cluster (SC) Topology.....	11
Figure 4 Cisco HX Data logical data paths.....	12
Figure 5 Cisco HX Data network design	13
Figure 6 Cisco HyperFlex HXAF220c-M5SX All-Flash Node.....	15
Figure 7 Cisco HyperFlex HXAF240c-M5SX All-Flash Node.....	16
Figure 8 Cisco HyperFlex HX220c-M5SX Hybrid Node.....	16
Figure 9 Cisco HyperFlex HX240c-M5SX Hybrid Node.....	16
Figure 10 Cisco HyperFlex HXAF220c – M5SN NVMe Node	17
Figure 11 Cisco HyperFlex HX240c-M5L Hybrid Node	17
Figure 12 Cisco HyperFlex HXAF220c-M4S All Flash Node	17
Figure 13 Cisco HyperFlex HXAF240c-M4SX All-Flash Node.....	18
Figure 14 Cisco HyperFlex HX220c-M4S Hybrid Node.....	18
Figure 15 Cisco HyperFlex HX240c-M4SX Hybrid Node.....	18

Document Introduction

Prepared By:
Cisco Systems, Inc.
170 West Tasman Dr.
San Jose, CA 95134

This document provides the basis for an evaluation of a specific Target of Evaluation (TOE), Cisco HyperFlex Systems HX Series running Cisco HyperFlex HX Data Platform Software, version 4.5(2a) This Security Target (ST) defines a set of assumptions about the aspects of the environment, a list of threats that the product intends to counter, a set of security objectives, a set of security requirements, and the IT security functions provided by the TOE which meet the set of requirements. Administrators of the TOE will be referred to as administrators, Authorized Administrators, TOE administrators, semi-privileged, privileged administrators, and security administrators in this document.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

© 2021 Cisco Systems, Inc. All rights reserved.

1. Security Target Introduction

This Security Target contains the following sections:

- Security Target Introduction [Section 1]
- Conformance Claims [Section 2]
- Security Problem Definition [Section 3]
- Security Objectives [Section 4]
- Security Requirements [Section 5]
- TOE Summary Specification [Section 6]
- Rationale [Section 7]
- References

The structure and content of this ST comply with the requirements specified in the Common Criteria (CC), Part 1, Annex A, and Part 3 Chapter 4.

1.1 ST and TOE Reference

This section provides information needed to identify and control this ST and its TOE.

Table 1 ST and TOE Identification

Name	Description
ST Title	Cisco HyperFlex Series 4.5 Systems HX Series Common Criteria Security Target
ST Version	3.0
Publication Date	22 December 2021
Vendor and ST Author	Cisco Systems, Inc.
TOE Reference	Cisco HyperFlex series 4.5(2a) Systems HX Series
TOE Hardware Models	Cisco HyperFlex HXAF220c – M5SX All – Flash Node Cisco HyperFlex HXAF240c – M5SX All – Flash Node Cisco HyperFlex HX220c – M5SX Hybrid Node Cisco HyperFlex HX240c – M5SX Hybrid Node Cisco HyperFlex HXAF220c - M5SN NVMe ¹ Node Cisco HyperFlex HX240c – M5L Hybrid Node Cisco HyperFlex HXAF220c – M4S All-Flash Node Cisco HyperFlex HXAF240c – M4SX All-Flash Node Cisco HyperFlex HX220c – M4S Hybrid Node Cisco HyperFlex HX240c – M4SX Hybrid Node
TOE Software Version	Cisco HyperFlex HX Data Platform Software, version 4.5(2a), for VMware ESXi
TOE Guidance	<i>Cisco HyperFlex Systems HX Series Common Criteria Operational User Guidance and Preparative Procedures, Version 3.0</i>
Keywords	HyperFlex, Convergent, Cluster, Storage, Data Protection, Authentication

¹ NVMe – Non-Volatile Memory express

1.2 TOE Overview

The TOE is the Cisco HyperFlex 4.5 Systems HX Series (herein after also referred to as Converged Hosts or TOE). The TOE is a hyper-convergent software-centric solution that tightly integrates computing, storage, networking and virtualization resources in a single hardware platform.

The TOE is installed in a hypervisor environment, such as VMware vSphere. The TOE manages the storage of a storage cluster that has a minimum three servers (HyperFlex HX Series Nodes (Converged Host)) with Solid-state disk (SSD) and Hard-disk drives (HDD) attached storage. The clustered servers are networked with switches and fabric interconnects. Optionally, non-storage servers, (compute nodes), can be included in the storage cluster. HX Data Platform manages the storage for the data and VMs stored on the associated storage cluster.

The HyperFlex HX Series installer is loaded on a UCS platform that is networked to the storage cluster to be managed. During the installation of the TOE, the initial cluster with at least three HyperFlex HX Series Nodes is created. The datastores are added to the storage cluster after the installation is complete. The HyperFlex HX Series provides a highly fault-tolerant distributed storage system that preserves data integrity and optimizes performance for virtual machine (VM) storage workloads.

The HyperFlex HX Series includes HyperFlex Connect (HX Connect) GUI that is used as the primary management tool for Cisco HyperFlex. Through this centralized point of control for the cluster, administrators can create volumes, monitor the data platform health, and manage resource use. Administrators can also use this data to predict when the cluster will need to be scaled.

The HyperFlex HX Series also includes a HXCLI with a set of commands that can be used to monitor and manage the storage clusters. The HXCLI also provides the Authorized Administrator the ability to add nodes as the storage capacity and the storage needs grow within the organization.

The following diagram, Figure 1 Cisco HyperFlex Standard Cluster Topology illustrates the Cisco HyperFlex system, composed of a pair of Cisco UCS Fabric Interconnects along with up to thirty-two HX-Series rack-mount servers per cluster. Up to thirty-two compute-only, servers can also be added per HyperFlex cluster. The diagram, Figure 2 Cisco HyperFlex Extended Cluster Topology illustrates the addition of Cisco UCS rack-mount servers and/or Cisco UCS 5108 Blade chassis, which house Cisco UCS blade servers that allows for additional compute resources in an extended cluster design. Up to eight separate HX clusters can be installed under a single pair of Fabric Interconnects. The two Fabric Interconnects, [both] connect to every HX-Series rack-mount server and both connect to every Cisco UCS 5108 blade chassis, and Cisco UCS rack-mount server.




Figure 1 Cisco HyperFlex Standard Cluster Topology




Figure 2 Cisco HyperFlex Extended Cluster Topology

Fabric Interconnects (FI) are deployed in pairs, wherein the two units operate as a management cluster, while forming two separate network fabrics, referred to as the A side and B side fabrics. Therefore, many design elements will refer to FI A or FI B, alternatively called fabric A or fabric B. Both Fabric Interconnects are always active, passing data on both network fabrics for a redundant and highly available configuration. Management services, including Cisco UCS Manager, are also provided by the two FIs but in a clustered manner, where one FI is the primary, and one is secondary, with a roaming clustered IP address. This primary/secondary relationship is only for the management cluster and has no effect on data transmission.

The following diagram, Figure 3 Cisco HyperFlex Stretched Cluster (SC) Topology illustrates the Stretched Cluster (SC). Note, the Stretched Cluster (SC) can only be deployed on the M5 Nodes, M4/M5 mixed cluster is not supported

The Stretched Cluster (SC) deployment is physically locating half of the cluster nodes in one location, while the remaining half are located in a distant secondary location. The data written to the stretched HyperFlex cluster is stored concurrently in both physical locations, therefore this system design provides for additional data protection and availability because the data in the cluster remains available and the cluster remains online, even if an entire site experiences a failure. Since all data written to the cluster is written simultaneously to the two sites, this design can be considered an active/active disaster recovery design. The recovery point objective (RPO), or the maximum amount of data that can potentially be lost prior to a failure is essentially zero, due to all data being immediately and continuously available in both sites.

The connection between the two sites is a dedicated (Private Fiber) Layer 2 (L2) data link that is protected by virtue of the VLAN that is stretched on the L2 as well. The storage data VLAN on the L2 is non-routed and isolated the same as it is on the switches locally in the standard or extended deployments. The management VLAN also behaves the same as it is on the switches locally in the standard or extended deployments and routed to places that have management access. As such, the management network is also extended over the L2 connection.

A Witness VM is part of the Stretched Cluster (SC) to avoid 'Split Brain' scenario, a third system (Witness VM) is required to break this tie or provide additional information and decision-making logic to prevent simultaneous takeover by the two sides of the Stretched Cluster. The Witness VM is a platform running ESXi server in the environment that is running the Cisco HyperFlex Data Platform Stretched Cluster Witness software. It is recommended that the Witness VM is physically separated from the two halves of the stretched cluster, installed within a protected area. The connection from the Witness VM is also a dedicated network connection to both of the other two sites within the Stretched Cluster (SC).




Figure 3 Cisco HyperFlex Stretched Cluster (SC) Topology

Trunk ports with VLANs are the access points between the physical and virtual environments. The VLANs are VLAN tagged External Switch VLAN Tagging (EST). The VLAN used for HX storage traffic must be able to traverse the network uplinks from the UCS domain, reaching FI A from FI B, and vice-versa. The VLANs are configured during install of the TOE, and then managed by VMware ESXi.

The Cisco HyperFlex system has communication pathways that fall into four defined zones as depicted in Figure 4 Cisco HX Data logical data paths below. The zones are defined as:

- Management Zone:** This zone comprises the connections needed to manage the physical hardware, the hypervisor hosts, and the storage platform controller virtual machines (SCVM). These interfaces and IP addresses need to be available to the Authorized Administrator that will manage and administer the TOE, throughout the LAN/WAN. This zone must provide access to Domain Name System (DNS) and Network Time Protocol (NTP) services and allow for secure HXCLI management using Secure Shell (SSHv2) and HTTPS/TLSv1.2 for secure HX Connect GUI management.

- **VM Zone:** This zone comprises the connections needed to service network IO to the guest VMs that will run inside the HyperFlex hyperconverged system. This zone typically contains multiple VLANs, that are trunked to the Cisco UCS Fabric Interconnects via the network uplinks and tagged with 802.1Q VLAN IDs. These interfaces and IP addresses need to be available to the Authorized Administrator that will manage and administer the TOE, throughout the LAN/WAN and the other computer endpoints which need to communicate with the guest VMs in the HX system, throughout the LAN/WAN.
- **Storage Zone:** This zone comprises the connections used by the Cisco HX Data Platform software, ESXi hosts and the storage controller VMs to service the HX Distributed Data File system. These interfaces and IP addresses need to be able to communicate with each other at all times for proper operation.
- **VMotion Zone:** This zone comprises the connections used by the ESXi hosts to enable vMotion of the guest VMs from host to host.

The following figure provides a visual depiction of the logical data path in the TOE deployment.




Figure 4 Cisco HX Data logical data paths

The following figure provides a visual depiction of the network design in the TOE deployment.




Figure 5 Cisco HX Data network design

1.3 TOE Product Type

The Cisco HyperFlex Systems HX-Series product type is a type of infrastructure system with a software-centric architecture that tightly integrates compute, storage, networking and virtualization resources.

The HyperFlex Systems HX Series provides connectivity and security services across the set of HX Series platforms that comprise the TOE. The TOE offers:

- Enterprise-class data management features that are required for complete lifecycle management and enhanced data protection in distributed storage
- Simplified data management that integrates storage functions into existing management tools and allowing instant provisioning for dramatically simplified daily operations
- Independent scaling of the computing, caching, and capacity tiers, giving you the flexibility to scale the environment based on evolving business needs
- Continuous data optimization with inline data deduplication and compression that increases resource utilization with more headroom for data scaling
- Dynamic data placement in node memory, enterprise-class flash memory (on solid-state disk [SSD] drives), and persistent storage tiers (on hard-disk drives [HDDs]) to optimize performance and resiliency—and to readjust data placement as you scale your cluster

The HyperFlex Systems HX Series delivers the combination of the essential features in a single solution.

1.3.1 Required non-TOE Hardware/Software/Firmware

The TOE supports the following hardware, software, and firmware components in its operational environment. Each component is identified as being required or not based on the claims made in this Security Target. All of the following environment components are supported by all TOE evaluated configurations.

Table 2 IT Environment Component

Component	Required	Usage/Purpose Description for TOE performance
DNS Server	Yes	The DNS Server is required to support IP addresses that are provided as host names for the various components that may be used for traffic and access control.
Fabric Interconnects (FI) (Cisco UCS)	Yes	The FIs provides the connections to the larger network including the switches and servers. The TOE deployment requires a minimum of two FIs for each Cisco HyperFlex Cluster to create high availability. The FI provides the single point of connectivity and hardware management that integrates Cisco HyperFlex HX Series nodes and Cisco UCS B-Series Blade Servers into a single unified cluster. The two FIs must be directly connected together using Ethernet cables between the two FI ports. This allows both the FIs to continuously monitor the status of each other. Cisco UCS Manager is an embedded software on the pair of fabric interconnects.
Management Workstation	Yes	<p>To manage the TOE via the HXCLI, this includes any IT Environment Management workstation installed with the SSHv2 client to support the TOE HXCLI interface for management of the TOE. The connection of the HXCLI management workstation to the TOE is protected through SSHv2 channel.</p> <p>To manage the TOE via the HX Connect GUI this includes any IT Environment Management workstation that supports the following browsers, Microsoft IE 11 or higher, Google Chrome, 54 or higher and Mozilla Firefox 52 or higher. The connection of the HX Connect management workstation to the TOE is protected through HTTPS/TLSv1.2 channel.</p>
NTP Server	Yes	The TOE supports communications with an NTP server to receive clock updates.
Private Fiber	Yes	In Stretched Cluster configuration, Private Fiber from the network provider is required to create the secured, privately-operated optical fiber network connection between the two sites.
SNMP Server	No	The server is required for the AutoSupport service, an alert notification service that is an optional service.
Switches	Yes	The switches provide data transmission and tracking
Trunk Ports	Yes	Trunk ports with VLANs are the access points between the physical and virtual environments. The VLANs are VLAN tagged External Switch VLAN Tagging (EST). The VLAN used for HX storage traffic must be able to traverse the network uplinks from the UCS domain, reaching FI A from FI B, and vice-versa. The VLANs are configured during install of the TOE, and then managed by VMware ESXi.

VMware vSphere ²	Yes	VMware vSphere ESXi 7.0 software preinstalled. vSphere Editions include Enterprise, Enterprise Plus, Standard, Essentials Plus, ROBO.
VMware vCenter	Yes	In the evaluated configuration, VMware vCenter functions as a remote authentication server providing the Authorized Administrator the capability of creating additional administrator accounts and storing the credentials.
Witness VM	Yes	The Witness VM is required in the Stretched Cluster deployment to avoid 'Split Brain' scenario. The Witness VM is a platform running ESXi server in the environment that is running the Cisco HyperFlex Data Platform Stretched Cluster Witness software.

1.4 TOE Description

This section provides an overview of the Cisco HyperFlex Systems HX Series Target of Evaluation (TOE). The TOE is comprised of both software and hardware.

The TOE software is Cisco HyperFlex HX Data Platform Software, version 4.5(2a), VMware ESXi version. Cisco HyperFlex HX Data Platform™ Software is a Cisco-developed highly configurable proprietary operating system that provides for efficient and effective scaling for storage capacity and performance.

The TOE hardware is the Cisco HyperFlex HX Series Nodes that includes the following models:

The small footprint Cisco HyperFlex HXAF220c-M5SX all-flash model contains:

- a 240 GB M.2 form factor solid-state disk (SSD) that acts as the boot drive,
- a 240 GB housekeeping SSD drive,
- either a single 375 GB Optane NVMe SSD, a 1.6 TB NVMe SSD or 400GB SAS SSD write-log drive,
- and six to eight 960GB or 3.8TB SATA SSD drives for storage capacity.



Figure 6 Cisco HyperFlex HXAF220c-M5SX All-Flash Node

This capacity optimized Cisco HyperFlex HXAF240c-M5SX all-flash model contains:

- a 240 GB M.2 form factor solid-state disk (SSD) that acts as the boot drive,
- a 240 GB housekeeping SSD drive, either a single 375 GB Optane NVMe SSD, a 1.6 TB NVMe SSD or 400GB SAS SSD write-log drive installed in a rear hot swappable slot,
- and six to twenty-three 960 GB or 3.8 TB SATA SSD drives for storage capacity.

² HyperFlex Systems may be pre-installed with VMware vSphere with licensing applied at purchase



Figure 7 Cisco HyperFlex HXAF240c-M5SX All-Flash Node

This small footprint Cisco HyperFlex HX220c-M5SX hybrid model contains:

- a minimum of six, and up to eight 1.8 terabyte (TB) or 1.2 TB SAS hard disk drives (HDD) that contribute to cluster storage capacity,
- a 240 GB SSD housekeeping drive, a 480 GB or 800 GB SSD caching drive,
- and a 240 GB M.2 form factor SSD that acts as the boot drive



Figure 8 Cisco HyperFlex HX220c-M5SX Hybrid Node

This small footprint Cisco HyperFlex HX240c-M5SX hybrid model contains:

- a minimum of six and up to twenty-three 1.8 TB or 1.2 TB SAS small form factor (SFF) harddisk drives (HDD) that contribute to cluster storage,
- a 240 GB SSD housekeeping drive, a single 1.6 TB SSD caching drive installed in a rear hot swappable slot,
- and a 240 GB M.2 form factor SSD that acts as the boot drive.



Figure 9 Cisco HyperFlex HX240c-M5SX Hybrid Node

Figure 10 below is a small footprint Cisco HyperFlex HXAF220c-M5SN NVMe Node that supports the following:

- 240 GB M.2 form factor SSD that acts as the boot drive
- 1 NVMe SSD caching and 1 NVMe SSD write-logging drive
- up to eight 1.8 TB or 4 TB NVMe SSD that contribute to storage capacity



Figure 10 Cisco HyperFlex HXAF220c – M5SN NVMe Node

This small footprint Cisco HyperFlex HX240c-M5L hybrid model contains:

- minimum of six and up to twelve 6 TB or 8 TB SAS large form factor (LFF) hard disk drives (HDD) that contribute to cluster storage,
- a 240 GB SSD housekeeping drive and a single 3.2 TB SSD caching drive, both installed in the rear hot swappable slots,
- and a 240 GB M.2 form factor SSD that acts as the boot drive



Figure 11 Cisco HyperFlex HX240c-M5L Hybrid Node

This small footprint Cisco HyperFlex HXAF220c-M4S all-flash model contains:

- two Cisco Flexible Flash (FlexFlash) Secure Digital (SD) cards that act as the boot drives,
- a single 120 GB or 240 GB solid-state disk (SSD) data-logging drive,
- a single 400 GB NVMe or a 400GB or 800 GB SAS SSD write-log drive,
- and six 960 GB or 3.8 terabyte (TB) SATA SSD drives for storage capacity.



Figure 12 Cisco HyperFlex HXAF220c-M4S All Flash Node

This small footprint Cisco HyperFlex HXAF240c-M4SX all-flash model contains:

- two FlexFlash SD cards that act as boot drives, a single 120 GB or 240 GB solid-state disk (SSD) data-logging drive,
- a single 400 GB NVMe or a 400GB or 800 GB SAS SSD write-log drive,
- and six to twenty-three 960 GB or 3.8 terabyte (TB) SATA SSD drives for storage capacity.



Figure 13 Cisco HyperFlex HXAF240c-M4SX All-Flash Node

This small footprint Cisco HyperFlex HX220c-M4S hybrid model contains:

- six 1.8 terabyte (TB) or 1.2 TB SAS HDD drives that contribute to cluster storage capacity,
- a 120 GB or 240 GB SSD housekeeping drive,
- a 480 GB SAS SSD caching drive,
- and two Cisco Flexible Flash (FlexFlash) Secure Digital (SD) cards that act as boot drives.



Figure 14 Cisco HyperFlex HX220c-M4S Hybrid Node

This small footprint Cisco HyperFlex HX240c-M4SX hybrid model contains:

- a minimum of six and up to twenty-three 1.8 TB or 1.2 TB SAS HDD drives that contribute to cluster storage,
- a single 120 GB or 240 GB SSD housekeeping drive,
- a single 1.6 TB SAS SSD caching drive,
- and two FlexFlash SD cards that act as the boot drives.



Figure 15 Cisco HyperFlex HX240c-M4SX Hybrid Node

1.5 TOE Evaluated Configuration

The TOE consists of one or more physical devices as specified in Section 1.5 Physical Scope of the TOE below and includes the Cisco HyperFlex HX Data Platform Software, version 4.5(2a), VMware ESXi version.

The TOE is installed in a hypervisor environment, such as VMware vSphere where it manages the storage clusters and datastores that has a minimum three servers, (TOE Converged hosts), with SSD and HDD attached storage. The clustered servers (TOE Converged hosts) are networked with switches and fabric interconnects. Optionally, non-storage servers, (compute nodes), can be included in the storage cluster (TOE Converged hosts). HyperFlex HX Series manages the storage for the data and VMs stored on the associated storage cluster (TOE Converged hosts).

The evaluated configuration is the configuration of the TOE that satisfies the requirements as defined in this Security Target (ST). For example.

- Security Audit – The TOE generates audit records to assist the Authorized Administrator in monitoring the security state of the HyperFlex HX Data Platform as well as trouble shooting various problems that arise throughout the operation of the system
- User Data Protection – The TOE provides access controls to the TOE Converged hosts, clusters and datastores.
- Identification and authentication – The TOE ensures that all Authorized Administrator are successfully identified and authenticated prior to gaining access to the TOE and terminates connection after a configured period of inactivity.
- Secure Management – The TOE provides secure administrative services for management of general TOE configuration and the security functionality provided by the TOE. All TOE administration occurs through the HX Connect GUI (over HTTPS/TLSv1.2) or the HXCLI (over SSHv2). All the TOE management functions are restricted to Authorized Administrator. The term "Authorized Administrator" is used in this ST to refer to any user account that has been assigned the privileges to perform the relevant action. The TOE provides the ability to perform the following actions:
 - Administer the TOE remotely
 - Manage access control attributes
 - Manage Authorized Administrator's security attributes
 - Review audit record logs
 - Configure and manage the system time
- Protection of the TSF - The TOE protects against interference and tampering by untrusted subjects by implementing identification and authentication, access control to the TOE Converged hosts, clusters and datastores and limits configuration options to the Authorized Administrator. Additionally, Cisco HyperFlex HX Series is not a general-purpose operating system and access to Cisco HyperFlex HX Series memory space is restricted to only Cisco HyperFlex HX Series functions. The TOE also provides the capability to protect unavailability of capabilities and system resources and to revert to a saved space in the case of hardware or system disruption of failure. Finally, the TOE is configured to use NTP to synchronize the TOE's clock with an external time source. This date and time is used as the timestamp that is applied to audit records generated by the TOE.
- TOE Access - The TOE can enforce the termination of inactive sessions after an Authorized Administrator configurable time-period. Once a session has been terminated, the TOE requires the Authorized Administrator to re-authenticate to establish a new session.

- Resource Utilization - Ensures the system, resources and data is preserved in case of a failure or degradation of services.
- Trusted Path/Channel – Ensures a trusted path is established between the TOE and the HX Connect GUI using HTTPS/TLSv1.2 and for the HXCLI using SSHv2

The TOE is remotely administered using HX Connect GUI and HXCLI, therefore, the management station must be connected to an internal network the supports HTTPS/TLSv1.2 and SSHv2 for secure connect to the TOE.

As noted above, the TOE is configured to connect to an NTP server and it is recommended that the NTP server be installed on an internal protected network, which is only accessible via the protected internal network. The NTP server is used for clock synchronization between services running on the Cisco HyperFlex Nodes, the storage controller VMs (storage controller) and ESXi hosts (Hypervisor).

1.6 Physical Scope of the TOE

The TOE is a hardware and software solution that makes up the Cisco HyperFlex Systems HX Series.

The hardware platforms include the Cisco HyperFlex HX Series as described in Table 3 Hardware Models and Description. For ordering of the TOE and delivery via commercial carriers, see

https://apps.cisco.com/ccw/cpc/guest/content/ucsSeriesDetails/series_hyperflex


The software is the Cisco HyperFlex HX Data Platform™ Software v4.5(2a), VMware ESXi version. The network, on which they reside, is considered part of the environment. The software file format for the HyperFlex Platform is an ova file. For ordering and downloading the TOE software, see <https://software.cisco.com/#>.


The TOE guidance documentation that is considered to be part of the TOE is the Cisco HyperFlex Systems HX Series Common Criteria Operational User Guidance and Preparative Procedures, a PDF document that can be downloaded from the <http://cisco.com> web site.


The TOE is comprised of the following physical specifications as described in Table 3 – Hardware Models and Descriptions below.


Table 3 Hardware Models and Description


Hardware Platform	Picture	Size	Power	Interfaces
-------------------	---------	------	-------	------------


<p>Cisco HyperFlex HXAF220c-M5SX All-Flash Node</p>		<p>Height 1.7 in. (4.32 cm) Width 16.89 in. (43.0 cm) including handles: 18.98 in. (48.2 cm) Depth 29.8 in. (75.6 cm) including handles: 30.98 in. (78.7 cm) Weight 37.5lbs (17.0kg)</p>	<p>Up to two of the following hot-swappable power supplies: 770 W (AC) or 1050 W (AC) power supply, or 1050 W V2 (DC)</p>	<p>Rear panel</p> <ul style="list-style-type: none"> • One 1-Gbps RJ-45 management port (Marvell 88E6176) • Two 10GBase-T LOM ports (Intel) • X550 controller embedded on the motherboard • One RS-232 serial port (RJ45 connector) • One DB15 VGA connector • Two USB 3.0 port connectors • One flexible modular LAN on motherboard (mLOM) slot that can accommodate various interface cards <p>Front panel</p> <ul style="list-style-type: none"> • One KVM console connector (supplies • Two USB 2.0 connectors, one VGA • DB15 video connector, and one serial port (RS232) RJ45 connector
---------------------------------------------------------	-----------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------


<p>Cisco HyperFlex HXAF240c-M5SX All-Flash Node</p>		<p>Height 3.43 in. (8.70 cm) Width (including slam latches) 17.65 in. (44.8 cm) Including handles: 18.96 in (48.2 cm) Depth 29.0 in. (73.8 cm) Including handles: 30.18 in (76.6 cm) Weight 37.0 lbs (16.8 kg)</p>	<p>Up to two of the following hot-swappable power supplies: 1050W (AC), or 1050 W V2 (DC) or 1600 W (AC)</p>	<p>Rear panel</p> <ul style="list-style-type: none"> • One 1-Gbps RJ-45 management port (Marvell 88E6176) • Two 10GBase-T LOM ports (Intel X550 controller embedded on the motherboard) • One RS-232 serial port (RJ45 connector) • One DB15 VGA connector • Two USB 3.0 port connectors • One flexible modular LAN on motherboard (mLOM) slot that can accommodate various interface cards <p>Front panel One KVM console connector (supplies two USB 2.0 connectors, one VGA)</p>
---------------------------------------------------------	-----------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------


<p>Cisco HyperFlex HX220c-M5SX Hybrid Node</p>		<p>Height 1.7 in. (4.32cm) Width 16.89 in. (43.0 cm) including handles: 18.98 in. (48.2 cm) Depth 29.8 in. (75.6 cm) including handles: 30.98 in. (78.7 cm) Weight 37.5 lbs (17.0 kg)</p>	<p>Up to two of the following hot-swappable power supplies: 770W (AC), or 1050 W (AC) or 1050W V2 (DC)</p>	<p>Rear panel</p> <ul style="list-style-type: none"> • One 1-Gbps RJ-45 management port (Marvell 88E6176) • Two 1/10GBase-T LOM ports (Intel X550 controller embedded on the motherboard) • One RS-232 serial port (RJ45 connector) • One DB15 VGA connector • Two USB 3.0 port connectors • One flexible modular LAN on motherboard (mLOM) slot that can accommodate various interface cards <p>Front panel</p> <ul style="list-style-type: none"> • One KVM console connector (supplies two USB 2.0 connectors, one VGA) • DB15 video connector, and one serial port (RS232) RJ45 connector)
--------------------------------------------------------	-----------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------


<p>Cisco HyperFlex HX240c-M5SX Hybrid Node</p>		<p>Height 3.43 in. (8.70 cm)</p> <p>Width 17.65 in.(43.0 cm) Including handles: 18.96 in (48.2 cm)</p> <p>Depth 29.0 in. (73.8 cm) Including handles: 30.18 in (76.6 cm)</p> <p>Weight 57.5 lbs (26.1 kg)</p>	<p>Up to two of the following hot-swappable power supplies: 1050W (AC), or 1050 W V2 (DC) or 1600 W (AC)</p>	<p>Rear panel</p> <ul style="list-style-type: none"> • One 1-Gbps RJ-45 management port (Marvell 88E6176) • Two 10GBase-T LOM ports (Intel X550 controller embedded on the motherboard) • One RS-232 serial port (RJ45 connector) • One DB15 VGA connector • Two USB 3.0 port connectors • One flexible modular LAN on motherboard (mLOM) slot that can accommodate various interface cards <p>Front panel One KVM console connector (supplies two USB 2.0 connectors, one VGA DB15 video connector, and one serial port (RS232))</p>
--------------------------------------------------------	-----------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------


<p>Cisco HyperFlex HXAF220c-M5SN NVMe Node</p>		<p>Height: 1.7 in. (4.32 cm)</p> <p>Width: 16.9 in. (43.0 cm) including handles: 18.98 in. (48.2 cm)</p> <p>Depth: 29.5 in. (74.0 cm) including handles: 31.0 in. (78.7 cm)</p> <p>Weight: 50.0lbs (22.7kg)</p>	<p>Up to two of the following hot-swappable power supplies: 770 W (AC) or 1050 W (AC) power supply, or 1050 W V2 (DC)</p>	<p>Rear panel</p> <ul style="list-style-type: none"> One 1-Gbps RJ-45 management port (Marvell 88E6176) Two 10GBase-T LOM ports (Intel X550 controller embedded on the motherboard) One RS-232 serial port (RJ-45 connector) One VGA video connector port (DB-15 connector) Two USB 3.0 port connectors One flexible modular LAN on motherboard (mLOM) slot that can accommodate various interface cards <p>Front panel</p> <ul style="list-style-type: none"> One KVM console connector (supplies) Two USB 2.0 connectors, one VGA DB-15 video connector, and one serial port (RS232) RJ-45 connector
--------------------------------------------------------	-----------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<p>Cisco HyperFlex HX240c-M5L Hybrid Node</p>		<p>Height 3.43 in (8.70 cm)</p> <p>Width 17.65 in (43.0 cm), including handles 18.96 in (48.2 cm)</p> <p>Depth 29.0 in (73.8 cm) Including handles 30.18 in (76.6 cm)</p> <p>Weight 45.5 lbs (20.4 kg)</p>	<p>Up to two of the following hot-swappable power supplies: 1050W (AC), or 1050 W V2 (DC) or 1600 W (AC)</p>	<p>Rear panel</p> <ul style="list-style-type: none"> • One 1-Gbps RJ-45 management port (Marvell 88E6176) • Two 10GBase-T LOM ports (Intel X550 controller embedded on the motherboard) • One RS-232 serial port (RJ45 connector) • One DB15 VGA connector • Two USB 3.0 port connectors • One flexible modular LAN on motherboard (mLOM) slot that can accommodate various interface cards <p>Front panel One KVM console connector (supplies two USB 2.0 connectors, one VGA DB15 video connector, and one serial port (RS232))</p>
-------------------------------------------------------	-----------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<p>Cisco HyperFlex HXAF220c-M4S All Flash Node</p>		<p>Height 1.7 in. (4.32cm)</p> <p>Width 16.89 in. (43.0 cm) including handles: 18.98 in. (48.2 cm)</p> <p>Depth 29.8 in. (75.6 cm) including handles: 30.98 in. (78.7 cm)</p> <p>Weight 37.5 lbs (17.0 kg)</p>	<p>Up to two of the following hot-swappable power supplies: 770W (AC),</p>	<p>Rear panel</p> <ul style="list-style-type: none"> • One DB15 VGA connector • One RJ45 serial port connector • Two USB 3.0 port connectors • One RJ-45 10/100/1000 Ethernet management port, using Cisco Integrated Management Controller (CIMC) firmware • Two Intel i350 embedded (on the motherboard) GbE LOM ports • One flexible modular LAN on motherboard (mLOM) slot that accommodates the Cisco UCS VIC 1227 MLOM - Dual Port 10Gb SFP+ interface card or the VIC 1387 Cisco VIC 1387 Dual Port 40Gb QSFP CNA. • Two PCIe 3.0 slots <p>Front panel</p> <ul style="list-style-type: none"> • One KVM console connector (supplies two USB 2.0 connectors, one VGA DB15 connector, and one serial port (RS232) RJ45 connector)
----------------------------------------------------	-----------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<p>Cisco HyperFlex HXAF240c-M4SX All-Flash Node</p>		<p>Height 3.43 in (8.70 cm)</p> <p>Width 17.65 in (43.0 cm), including handles 18.96 in (48.2 cm)</p> <p>Depth 29.0 in (73.8 cm) Including handles 30.18 in (76.6 cm)</p> <p>Weight 62.7 lbs (28.4 kg)</p>	<p>Up to two of the following hot-swappable power supplies: 650W (AC), 930W (DC), 1200W (AC) or 1400W(AC)</p>	<p>Rear panel</p> <ul style="list-style-type: none"> • One DB15 VGA connector • One RJ45 serial port connector • Two USB 3.0 port connectors • One RJ-45 10/100/1000 Ethernet management port, using Cisco Integrated Management Controller (CIMC) firmware • Two Intel i350 embedded (on the motherboard) GbE LOM ports • One flexible modular LAN on motherboard (mLOM) slot that accommodates the Cisco UCS VIC1227 VIC MLOM - Dual Port 10Gb SFP+ and Cisco VIC 1387 Dual Port 40Gb QSFP CNA MLOM interface cards. • Two PCIe 3.0 slots <p>Front panel</p> <ul style="list-style-type: none"> • One KVM console connector (supplies two USB 2.0 connectors, one VGA DB15 video connector, and one serial port (RS232) RJ45 connector
---------------------------------------------------------	-----------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<p>Cisco HyperFlex HX220c-M4S Hybrid Node</p>		<p>Height 1.7 in. (4.32cm)</p> <p>Width 16.89 in. (43.0 cm) including handles: 18.98 in. (48.2 cm)</p> <p>Depth 29.8 in. (75.6 cm) including handles: 30.98 in. (78.7 cm)</p> <p>Weight 37.9 lbs (17.2 kg)</p>	<p>Up to two of the following hot-swappable power supplies: 770W (AC),</p>	<p>Rear panel</p> <ul style="list-style-type: none"> • One DB15 VGA connector • One RJ45 serial port connector • Two USB 3.0 port connectors • One RJ-45 10/100/1000 Ethernet management port, using Cisco Integrated Management Controller (CIMC) firmware • Two Intel i350 embedded (on the motherboard) GbE LOM ports • One flexible modular LAN on motherboard (mLOM) slot that accommodates the Cisco UCS VIC 1227 MLOM - Dual Port 10Gb SFP+ interface card • Two PCIe 3.0 slots <p>Front panel</p> <ul style="list-style-type: none"> • One KVM console connector (supplies two USB 2.0 connectors, one VGA DB15 connector, and one serial port (RS232) RJ45 connector)
-----------------------------------------------	-----------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<p>Cisco HyperFlex HX240c-M4SX Hybrid Node</p>		<p>Height 3.43 in (8.70 cm)</p> <p>Width 17.65 in (43.0 cm), including handles 18.96 in (48.2 cm)</p> <p>Depth 29.0 in (73.8 cm) Including handles 30.18 in (76.6 cm)</p> <p>Weight 62.7 lbs (28.4 kg)</p>	<p>Up to two of the following hot-swappable power supplies: 650W (AC), 930W (DC), 1200W (AC) or 1400W(AC)</p>	<p>Rear panel</p> <ul style="list-style-type: none"> • One DB15 VGA connector • One RJ45 serial port connector • Two USB 3.0 port connectors • One RJ-45 10/100/1000 Ethernet management port, using Cisco Integrated Management Controller (CIMC) firmware • Two Intel i350 embedded (on the motherboard) GbE LOM ports • One flexible modular LAN on motherboard (mLOM) slot that accommodates the Cisco UCS VIC1227 VIC MLOM - Dual Port 10Gb SFP+ and Cisco VIC 1387 Dual Port 40Gb QSFP CNA MLOM interface cards. • Two PCIe 3.0 slots <p>Front panel</p> <ul style="list-style-type: none"> • One KVM console connector (supplies two USB 2.0 connectors, one VGA DB15 video connector, and one serial port (RS232) RJ45 connector
------------------------------------------------	-----------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

1.6.1 TOE Documentation

This section identifies the guidance documentation included in the TOE. The documentation for the Cisco HyperFlex Systems HX Series comprises:

- *Cisco HyperFlex Systems HX Series Common Criteria Operational User Guidance and Preparative Procedures, v3.0* dated [15 December 2021].

1.7 Logical Scope of the TOE

The TOE is comprised of several security features. Each of the security features consists of several security functionalities, as identified below.

- Security Audit
- User data protection
- Identification and Authentication
- Security Management
- Protection of the TSF
- Resource Utilization
- TOE Access
- Trusted Path

These features are described in more detail in the subsections below.

1.1.1 Security Audit

The TOE generates audit messages that identify specific TOE operations. For each event, the TOE records the date and time of each event, the type of event, the subject identity, and the outcome of the event. Auditable events include:

- all use of the user identification mechanism;
- all use of the authentication mechanism;
- all modification in the behaviour of the functions in the TSF;
- all modifications of the default settings;
- all modifications to the values of the TSF data;
- use of the management functions;
- changes to the time;
- terminations of an interactive session; and
- attempts to use the trusted path functions

The TOE will write audit records to the local logging buffer by default. The TOE provides an interface available for the Authorized Administrator to delete audit data stored locally on the TOE to manage the audit log space.

The logs can be viewed on the TOE using HX Connect GUI interfaces. The records include the date/time the event occurred, the event/type of event, the user associated with the event, and additional information of the event and its success and/or failure.

1.7.1 User Data Protection

The TOE provides the Authorized Administrator with the ability to control remote host (VMs) access to the TOE Converged hosts, clusters and datastores with whitelisting.

The whitelist controls access using IP addresses. If the Remote Host (VM) host IP address is included on the whitelist and there is sufficient storage capacity, access is granted otherwise access is denied.

The three sets of addressing that may be used:

- Management addresses identify the TOE Converged hosts and their clusters and datastores and the Storage Controller VM management interfaces
- VM addresses identify the guest VMs that run in the TOE HyperFlex hyperconverged system
- Storage addresses that are used by Cisco HX Data Platform software, ESXi hosts, and the storage controller VMs to service the HX Distributed Filesystem. These interfaces and IP addresses need to be able to communicate with each other at all times for proper operation

1.7.2 Identification and Authentication

The TOE provides authentication services for the Authorized Administrator to connect to the TOE's HX Connect GUI and HX CLI administrator interfaces. The TOE requires the Authorized Administrator to be successfully identified and authenticated prior to being granted access to any of the management functionality. The TOE can be configured to enforce password minimum length as well as mandatory password complexity rules. The TOE provides administrator authentication against a local user database. Password-based authentication is performed on the HX Connect GUI and HX CLI session interface connections.

For each Authorized Administrator account, they must have a unique username. For authentication purposes, a password is required for each Authorized Administrator account.

1.7.3 Security Management

The TOE provides secure administrative services for management of general TOE configuration and the security functionality provided by the TOE. All TOE administration occurs through the HX Connect GUI using HTTPS/TLSv1.2 and for the HX CLI using SSHv2 secure connection.

The TOE provides the ability to securely:

- Administer the TOE remotely
- Manage access control attributes
- Manage Authorized Administrator's security attributes, noting the TOE allows for more than one administrator account to be configured. Each Authorized Administrator must be assigned a unique username and password
- Review audit record logs
- Configure and manage the system time

1.7.4 Protection of the TSF

The TOE protects against interference and tampering by untrusted subjects by implementing identification, authentication and limit configuration options to the Authorized Administrator. Additionally, Cisco HyperFlex HX Data Platform™ Software v4.5(2a) is not a general-purpose operating system and access to the HyperFlex memory space is restricted to only Cisco HyperFlex v4.5(2a) functions.

The TOE provides the capability called native snapshot to save the current state of the VMs, so the Authorized Administrator has the option to revert to the saved state in the case of disruption or failure.

The TOE internally maintains the date and time. This date and time is used as the timestamp that is applied to audit records generated by the TOE. The TOE is configured to use NTP to synchronize the TOE's clock with an external time source. It is recommended that NTP server be installed on the internal protected network for time services, which is only accessible via

the protected internal network. The NTP server is used for clock synchronization between services running on the Cisco HyperFlex HX Series Nodes, the storage controller VMs (storage controller) and ESXi hosts (Hypervisor).

1.7.5 Resource Utilization

The TOE protects against unavailability of capabilities and system resources caused by failure or degradation of services by supporting redundancy and failover capabilities of the storage management network and the storage data networks.

1.7.6 TOE Access

The TOE enforces the termination of inactive sessions after an Authorized Administrator configurable time-period has expired. Once a session has been terminated, the TOE requires the Authorized Administrator to re-authenticate to establish a new session.

1.7.7 Trusted Path/Channels

The TOE allows trusted paths to be established to itself from remote administrators over HTTPS/TLSv1.2 for remote HX Connect GUI and SSHv2 for remote HX CLI access.

1.8 Excluded Functionality

The following functionality is excluded from the evaluation.

Table 4 Excluded Functionality and Rationale

Function Excluded	Rationale
Telnet	Telnet Sends authentication data in plain text. This feature is disabled by default and must remain disabled in the evaluated configuration.

2. Conformance Claims

2.1 Common Criteria Conformance Claim

The ST and the TOE it describes are conformant with the following CC specifications:

- Common Criteria for Information Technology Security Evaluation Part 2: Security Functional Components, Version 3.1, Revision 5, April 2017 o Part 2 Conformant
 - Common Criteria for Information Technology Security Evaluation Part 3: Security Assurance Components, Version 3.1, Revision 5, April 2017 o Part 3 Conformant

The ST and TOE are package conformant to evaluation assurance package:

- EAL2

2.2 Protection Profile Conformance Claim

This ST claims no compliance to any Protection Profiles.

3. Security Problem Definition

This section describes the following security environment in which the TOE is intended to be used.

- Significant assumptions about the TOE's operational environment.
- IT related threats to the organization countered by the TOE
- Environmental threats requiring controls to provide sufficient protection.
- Organizational Security Policies for the TOE as appropriate.

This document identifies assumptions as A.assumption with "assumption" specifying a unique name. Threats are identified as T.threat with "threat" specifying a unique name.

3.1 Assumptions

The specific conditions listed in the following subsections are assumed to exist in the TOE's environment. These assumptions include both practical realities in the development of the TOE security requirements and the essential environmental conditions on the use of the TOE.

Table 5 TOE Assumptions

Assumption	Assumption Definition
A.ADMIN	All Authorized Administrator are assumed not evil, will follow the administrative guidance and will not disrupt the operation of the TOE intentionally.
A.CONNECTIONS	The operational environment in which the TOE is installed will allow the users of the TOE to access the stored information.
A.LOCATE	The processing resources of the TOE and those services provided by the operational environment will be located within controlled access facilities, which will prevent unauthorized physical access.

3.2 Threats

The following table lists the threats addressed by the TOE and the IT Environment. The assumed level of expertise of the attacker for all the threats identified below is Basic.

Table 6 Threats

Threat	Threat Definition
T.ACCOUNTABILITY	An authorized administrator is not held accountable for their actions on the TOE because the audit records are not generated, do not include the required data, including properly sequenced through application of correct timestamps or reviewed.
T.NOAUTH	An unauthorized person (attacker) may attempt to bypass the security of the TOE so as to access data and use security functions and/or non-security functions provided by the TOE to disrupt operations of the TOE.
T.RESOURCE_AVAILABILITY	The TOE user data could become corrupted or unavailable due to hardware or system operation failures.

3.3 Organizational Security Policies

No Organizational Security Policies (OSPs) have been defined for this TOE.

4. Security Objectives

This section identifies the security objectives of the TOE and the IT Environment. The security objectives identify the responsibilities of the TOE and the TOE's IT environment in meeting the security needs.

This document identifies objectives of the TOE as O.objective with objective specifying a unique name. Objectives that apply to the IT environment are designated as OE.objective with objective specifying a unique name.

4.1 Security Objectives for the TOE

The following table, Security Objectives for the TOE, identifies the security objectives of the TOE. These security objectives reflect the stated intent to counter identified threats and/or comply with any security policies identified. An explanation of the relationship between the objectives and the threats/policies is provided in the rationale section of this document.

Table 7 Security Objectives for the TOE

TOE Security Objective	TOE Security Objective Definition
O.ACCESS_CONTROL	The TOE will restrict access to the TOE management functions to the Authorized Administrator.
O.ADMIN	The TOE will provide the Authorized Administrator with a set of privileges to isolate administrative actions and to make the administrative functions available remotely.
O.AUDIT_GEN	The TOE will generate audit records that will include the event, the time that the event occurred, the identity of the user performing the event and the outcome of the event.
O.AVAILABILITY	The TOE will provide mechanisms to maintain a secure state and mitigate against user data loss or corruption due to hardware or system operation failures.
O.AUDIT_VIEW	The TOE will provide the Authorized Administrator the capability to review audit data.
O.DATA	The TOE will protect the configuration and user data from unauthorized disclosure.
O.IDAUTH	The TOE must uniquely identify and authenticate the claimed identity of all administrative users before granting management access.
O.SELFPRO	The TOE must protect itself against attempts by unauthorized users to bypass, deactivate, or tamper with TOE security functions.
O.TIME	The TOE will provide a reliable time stamp for its own use.

4.2 Security Objectives for the Environment

All of the assumptions stated in Section 3.1 are considered to be security objectives for the environment. The following are the non-IT security objectives, which, in addition to those assumptions, are to be satisfied without imposing technical

requirements on the TOE. That is, they will not require the implementation of functions in the TOE hardware and/or software. Thus, they will be satisfied largely through application of procedural or administrative measures.

Table 8 Security Objectives for the Environment

Environment Security Objective	IT Environment Security Objective Definition
OE.ADMIN	The Authorized Administrator are well trained and trusted to manage the TOE and to configure the IT environment and required non-TOE devices for the proper network support.
OE.CONNECTION	The operational environment will have the required protected network support for the operation of the TOE to prevent unauthorized access to the TOE.
OE_SC.CONNECTION	The operational environment will have the required Private Fiber network when the TOE is deployed in the Stretched Cluster configuration to prevent unauthorized access to the TOE.
OE.LOCATE	The processing resources of the TOE and those services provided by the operational environment will be located within controlled access facilities, which will prevent unauthorized physical access.

5. Security Requirements

This section identifies the Security Functional Requirements for the TOE. The Security Functional Requirements included in this section are derived from Part 2 of the *Common Criteria for Information Technology Security Evaluation, Version 3.1, Revision 5, dated: April 2017* and all international interpretations.

5.1 Conventions

The CC defines operations on Security Functional Requirements: assignments, selections, assignments within selections and refinements. This document uses the following font conventions to identify the operations defined by the CC:

Table 9 Security Requirement Conventions

Convention	Indication
Assignment	Allows the specification of an identified parameter. Assignments are indicated using bold and are surrounded by brackets (e.g., [assignment]). Note that an assignment within a selection would be identified in italics and with embedded bold brackets (e.g., [[<i>selected-assignment</i>]])
Selection	Allows the specification of one or more elements from a list. Selections are indicated using bold italics and are surrounded by brackets (e.g., [<i>selection</i>]).

Iteration	Allows a component to be used more than once with varying operations. In the ST, iteration is indicated by a number placed at the end of the component. (e.g., (1), (2), (3).)
Refinement	Allows the addition of details. Refinements are indicated using bold, for additions, and strike-through, for deletions (e.g., “... all objects ...” or “... some big things ...”).
Extended Requirements	Are identified with “(EXT)” in of the functional class/name and are those not found in Part 2 of the CC.
Other	Sections of the ST use bolding to highlight text of special interest, such as captions.

5.2 TOE Security Functional Requirements

This section identifies the Security Functional Requirements for the TOE. The TOE Security Functional Requirements that appear in the following table are described in more detail in the following subsections.

Table 10 Security Functional Requirements

Class Name	Component Identification	Component Name
FAU: Security Audit	FAU_GEN.1	Audit data generation
	FAU_GEN.2	User Identity Association
	FAU_SAR.1	Audit Review
	FAU_STG.1	Protected Audit Event Storage
FDP: User data protection	FDP_ACC.2	Complete access control
	FDP_ACF.1	Security attribute based access control
FIA: Identification and authentication	FIA_ATD.1	Password Management
	FIA_SOS.1	Authentication Failure Handling
	FIA_UAU.2	Password-based Authentication Mechanism
	FIA_UAU.7	Protected authentication feedback
	FIA_UID.2	User identification before any action
FMT: Security management	FMT_MSA.1	Secure Security Attributes (Access Control)
	FMT_MSA.3	Static Attribute Initialization (Access Control)
	FMT_MTD.1	Management of TSF Data
	FMT_SMF.1	Specification of Management Functions

Class Name	Component Identification	Component Name
	FMT_SMR.1	Security Roles
FPT: Protection of the TSF	FPT_FLS.1	Failure with preservation of secure state
	FPT_STM.1	Reliable Time Stamps
FRU: Resource Utilization	FRU_FLT.2	Limited fault tolerance
FTA: TOE Access	FTA_SSL.3	TSF-initiated Termination
FTP: Trusted path	FTP_TRP.1	Trusted Path

5.3 Security Functional Requirements

5.3.1 Class: Security Audit (FAU)

5.3.1.1 FAU_GEN.1 – Audit Data Generation

FAU_GEN.1.1 The TSF shall be able to generate an audit record of the following auditable events:

- a) Start-up and shutdown of the audit functions;
- b) All auditable events for the [*not specified*] level of audit **specified in Table 11 Auditable Events**; and
- c) [**no additional events**].

FAU_GEN.1.2 The TSF shall record within each audit record at least the following information:

- a) Date and time of the event, type of event, subject identity, and the outcome (success or failure) of the event; and
- b) For each audit event type, based on the auditable event definitions of the functional components included in the CPP/ST, [**information specified in the Additional Audit Record Contents column of Table 11 Auditable Events**].

Table 11 Auditable Events

SFR	Auditable Event	Additional Audit Record Contents
FAU_GEN.1	None.	None.
FAU_GEN.2	None.	None.
FAU_SAR.1	None.	None.
FAU_STG.1	None.	None.
FDP_ACC.2	None	None.
FDP_ACF.1	None	None.
FIA_ATD.1	None	None.
FIA_SOS.1	None	None.

SFR	Auditable Event	Additional Audit Record Contents
FIA_UAU.2	All use of the authentication mechanism.	Provided user identity, origin of the attempt (e.g., IP address).
FIA_UAU.7	None.	None.
FIA_UID.2	All use of the identification mechanism.	Provided user identity, origin of the attempt (e.g., IP address).
FMT_MSA.1	None	None.
FMT_MSA.3	Modifications of the default setting of permissive or restrictive rules and all modifications of the initial values of security attributes.	None
FMT_MTD.1	All modifications to the values of TSF data	The identity of the authorized administrator performing the operation.
FMT_SMF.1	Use of the management functions	The identity of the authorized administrator performing the operation.
FMT_SMR.1	None	None.
FPT_FLS.1	Failure of the TSF	None
FPT_STM.1	Changes to the time.	The identity of the authorized administrator performing the operation.
FRU_FLT.2	Any failure detected by the TSF	None
FTA_SSL.3	Termination of an interactive session by the session locking mechanism.	None
FTP_TRP.1	Attempts to use the trusted path functions.	Identification of the user associated with all trusted path invocations including failures, if available.

5.3.1.2 FAU_GEN.2 – User Identity Association

FAU_GEN.2.1 For audit events resulting from actions of identified users, the TSF shall be able to associate each auditable event with the identity of the user that caused the event.

5.3.1.3 FAU_SAR.1 – Audit Review

FAU_SAR.1.1 The TSF shall provide [**authorized administrator**] with the capability to read [**all TOE audit trail data**] from the audit records.

FAU_SAR.1.2 The TSF shall provide the audit records in a manner suitable for the user to interpret the information.

5.3.1.4 FAU_STG.1 – Protected Audit Event Storage

FAU_STG.1.1 The TSF shall protect the stored audit records in the audit trail from unauthorized deletion.

FAU_STG.1.2 The TSF shall be able to [**prevent**] unauthorized modifications to the stored audit records in the audit trail.

5.3.2 Class: User Data Protection (FDP)

5.3.2.1 FDP_ACC.2 Complete access control

FDP_ACC.2.1 The TSF shall enforce the [Access Control SFP] on [

Subjects:

- Remote Host (VMs);

Objects:

- Clusters (Converged Host),
- Datastores]

and all operations among subjects and objects covered by the SFP.

FDP_ACC.2.2 The TSF shall ensure that all operations between any subject controlled by the TSF and any object controlled by the TSF are covered by an access control SFP

5.3.2.2 FDP_ACF.1 Security attribute based access control

FDP_ACF.1.1 The TSF shall enforce the [Access Control SFP] to objects based on the following: [

Subject security attributes:

- Remote Host IP address

Object security attributes:

- Cluster Datastore IP address
- Whitelist
- Storage capacity

].

FDP_ACF.1.2 The TSF shall enforce the following rules to determine if an operation among controlled subjects and controlled objects is allowed: [if the Remote Host IP address is on the Cluster Datastore whitelist, access is granted].

FDP_ACF.1.3 The TSF shall explicitly authorise access of subjects to objects based on the following additional rules: [none].

FDP_ACF.1.4 The TSF shall explicitly deny access of subjects to objects based on the following additional rules [if the Cluster Datastore storage space is not available, access is denied].

5.3.3 Class: Identification and Authentication (FIA)

5.3.3.1 FIA_ATD.1 User attribute definition

FIA_ATD.1.1 The TSF shall maintain the following list of security attributes belonging to individual users: [For interactive users:

- a) user identity;

b) password].

5.3.3.2 FIA_SOS.1 Verification of secrets

FIA_SOS.1.1 The TSF shall provide a mechanism to verify that secrets meet [**at least eight characters long; includes upper and lower alpha characters and alpha numeric characters**].

5.3.3.3 FIA_UAU.2 – User authentication before any action

FIA_UAU.2.1 The TSF shall require each user to be successfully authenticated before allowing any other TSF-mediated actions on behalf of that user.

5.3.3.4 FIA_UAU.7 – Protected Authentication Feedback

FIA_UAU.7.1 The TSF shall provide only [**no feedback or any locally visible representation of the user-entered password**] to the user while the authentication is in progress.

5.3.3.5 FIA_UID.2 – X.509 Certificate Validation

FIA_UID.2.1 The TSF shall require each user to be successfully identified before allowing any other TSF-mediated actions on behalf of that user.

5.3.4 Class: Security Management (FMT)

5.3.4.1 FMT_MSA.1 – Management of security attributes

FIA_MSA.1.1 The TSF shall enforce the [**Access Control SFP**] to restrict the ability to [**modify, [none]**] the security attributes [**listed in section FDP_ACF1.1**] to [**Authorized Administrator**].

5.3.4.2 FMT_MSA.3 –Static attribute initialization

FMT_MSA.3.1 The TSF shall enforce the [**Access Control SFP**] to provide [**restrictive**] default values for security attributes that are used to enforce the SFP.

FMT_MSA.3.2 The TSF shall allow [**Authorized Administrator**] to specify alternative initial values to override the default values when an object or information is created.

5.3.4.3 FMT_MTD.1– Management of TSF Data

FMT_MTD.1.1 The TSF shall restrict the ability to [**modify**] the [**all TSF data**] to [**Authorized Administrator**].

5.3.4.4 FMT_SMF.1 – Specification of Management Functions

FMT_SMF.1.1 The TSF shall be capable of performing the following management functions: [

- **Ability to administer the TOE locally and remotely**
- **Manage the access control security attributes**
- **Manage Authorized Administrator’s security attributes**
- **Review audit record logs**
- **Configure and manage the system time**].

5.3.4.5 FMT_SMR.1 –Security Roles

FMT_SMR.1.1 The TSF shall maintain the following roles [**Authorized Administrator**].

FMT_SMR.1.2 The TSF shall be able to associate users with roles.

5.3.5 Class: Protection of the TSF (FPT)

5.3.5.1 FPT_FLS.1 – Failure with preservation of secure state

FPT_FLS.1.1 The TSF shall preserve a secure state when the following types of failures occur: [

- **Failure of a Node (HX Data Platform) within a Cluster**
 - **Failure of one or more HDD of a Node (HX Data Platform) within a Cluster**
 - **Failure of one or more SSD of a Node (HX Data Platform) within a Cluster**
-].

5.3.5.2 FPT_STM.1 – Reliable time stamps

FPT_STM.1.1 The TSF shall be able to provide reliable time stamps **for its own use**.

5.3.6 Resource Utilisation (FRU)

5.3.6.1 FRU_FLT.2 Limited Fault Tolerance

FRU_FLT.2.1 The TSF shall ensure the operation of all the TOE's capabilities when the following failures occur: [

- **Failure of a Node (HX Data Platform) within a Cluster**
- **Failure of one or more HDD of a Node (HX Data Platform) within a Cluster**
- **Failure of one or more SSD of a Node (HX Data Platform) within a Cluster**

].

5.3.7 Class: TOE Access (FTA)

5.3.7.1 FTA_SSL.3 – TSF-initiated Termination

FTA_SSL.3.1 The TSF shall terminate a remote interactive session after a [**Authorized Administrator configurable time interval of session inactivity**].

5.3.8 Class: Trusted Path (FTP)

5.3.8.1 FTP_TRP.1 – Trusted Path

FTP_TRP.1.1 The TSF shall provide a communication path between itself and [**remote**] users that is logically distinct from other communication paths and provides assured identification of its end points and protection of the communicated data from [**modification, disclosure**].

FTP_TRP.1.2 The TSF shall permit [**remote users**] to initiate communication via the trusted path.

FTP_TRP.1.3 The TSF shall require the use of the trusted path for [**initial user authentication, [management of the TOE via administrative interfaces]**].

5.4 TOE SFR Dependencies Rationale

This section of the Security Target demonstrates that the identified TOE Security Functional Requirements include the appropriate hierarchical SFRs and dependent SFRs. The following table lists the TOE Security Functional Components and the Security Functional Components, each are hierarchical to and dependent upon and any necessary rationale.

Table 12 SFR Dependency Rationale

SFR	Dependency	Rationale
FAU_GEN.1	FPT_STM.1	Met by: FPT_STM.1
FAU_GEN.2	FAU_GEN.1 FIA_UID.1	Met by: FAU_GEN.1 FIA_UID.2
FAU_SAR.1	FAU_GEN.1	Met by: FAU_GEN.1
FAU_STG.1	FAU_GEN.1	Met by: FAU_GEN.1
FDP_ACC.2	FDP_ACF.1	Met by: FDP_ACF.1
FDP_ACF.1	FDP_ACC.1 FMT_MSA.3	Met by: FDP_ACC.2 FMT_MSA.3
FIA_ATD.1	No dependencies	N/A
FIA_SOS.1	No dependencies	N/A
FIA_UAU.2	FIA_UID.1	Met by: FIA_UID.1
FIA_UAU.7	FIA_UAU.1	Met by: FIA_UAU.2
FIA_UID.2	No dependencies	N/A
FMT_MSA.1	FDP_ACC.1 FMT_SMR.1 FMT_SMF.1	Met by: FDP_ACC.2 FMT_SMR.1 FMT_SMF.1

SFR	Dependency	Rationale
FMT_MSA.3	FMT_MSA.1 FMT_SMR.1	Met by: FMT_SMR.1 FMT_MSA.1
FMT_MTD.1	FMT_SMF.1 FMT_SMR.1	Met by: FMT_SMF.1 FMT_SMR.1
FMT_SMF.1	No dependencies	N/A
FMT_SMR.1	FIA_UID.1	Met by: FIA_UID.2
FPT_FLS.1	No dependencies	N/A
FPT_STM.1	No dependencies	N/A
FRU_FLT.2	FPT_FLS.1	Met by: FPT_FLS.1
FTA_SSL.3	No dependencies	N/A
FTP_TRP.1	No dependencies	N/A

5.5 Security Assurance Requirements

5.5.1 SAR Requirements

The TOE assurance requirements for this ST are EAL2 derived from Common Criteria Version 3.1, Revision 4. The assurance requirements are summarized in the table below.

Table 13 SAR Requirements

Assurance Class	Components	Components Description
Development	ADV_ARC.1	Architectural Design with domain separation and non-bypassability
	ADV_FSP.2	Security-enforcing functional specification
	ADV_TDS.1	Basic design
Guidance Documents	AGD_OPE.1	Operational user guidance
	AGD_PRE.1	Preparative User guidance
Life Cycle Support	ALC_CMC.2	Use of a CM system
	ALC_CMS.2	Parts of the TOE CM coverage
	ALC_DEL.1	Delivery procedures

Assurance Class	Components	Components Description
Tests	ATE_COV.1	Evidence of coverage
	ATE_FUN.1	Functional testing
	ATE_IND.2	Independent testing – sample
Vulnerability Assessment	AVA_VAN.2	Vulnerability analysis

5.5.2 Security Assurance Requirements Rationale

This Security Target claims conformance to EAL2. This target was chosen to ensure that the TOE has a moderate level of assurance in enforcing its security functions when instantiated in its intended environment which imposes no restrictions on assumed activity on applicable networks.

5.6 Assurance Measures

The TOE satisfies the identified assurance requirements. The table below identifies the Assurance Measures applied by Cisco to satisfy the assurance requirements.

Table 14 Assurance Measures

Assurance Component	Rationale
ADV_ARC.1	The architecture description provides the justification how the security functional requirements are enforced, how the security features (functions) cannot be bypassed, and how the TOE protects itself from tampering by untrusted active entities. The architecture description also identifies the system initialization components and the processing that occurs when the TOE is brought into a secure state (e.g. transition from a down state to the initial secure state (operational)).
ADV_FSP.2	The functional specification describes the external interfaces of the TOE; such as the means for a user to invoke a service and the corresponding response of those services. The description includes the interface(s) that enforces a security functional requirement, the interface(s) that supports the enforcement of a security functional requirement, and the interface(s) that does not enforce any security functional requirements. The interfaces are described in terms of their purpose (general goal of the interface), method of use (how the interface is to be used), parameters (explicit inputs to and outputs from an interface that control the behavior of that interface), parameter descriptions (tells what the parameter is in some meaningful way), and error messages (identifies the condition that generated it, what the message is, and the meaning of any error codes). The development evidence also contains a tracing of the interfaces to the SFRs described in this ST.
ADV_TDS.1	The TOE design describes the TOE security functional (TSF) boundary and how the TSF implements the security functional requirements. The design description includes the decomposition of the TOE into subsystems and/or modules, thus providing the purpose of the subsystem/module, the behavior of the subsystem/module and the actions the subsystem/module performs. The description also identifies the subsystem/module as SFR (security function requirement) enforcing, SFR supporting, or SFR non-interfering; thus identifying the interfaces as described in the functional specification. In addition, the TOE design describes the interactions among or between the subsystems/modules; thus providing a description of what the TOE is doing and how.

Assurance Component	Rationale
AGD_OPE.1	The Administrative Guide provides the descriptions of the processes and procedures of how the administrative users of the TOE can securely administer the TOE using the interfaces that provide the features and functions detailed in the guidance.
AGD_PRE.1	The Installation Guide describes the installation, generation, and startup procedures so that the users of the TOE can put the components of the TOE in the evaluated configuration.
ALC_CMC.2 ALC_CMS.2	The Configuration Management (CM) document(s) describes how the consumer (end-user) of the TOE can identify the evaluated TOE (Target of Evaluation). The CM document(s), identifies the configuration items, how those configuration items are uniquely identified, and the adequacy of the procedures that are used to control and track changes that are made to the TOE. This includes details on what changes are tracked, how potential changes are incorporated, and the degree to which automation is used to reduce the scope for error.
ALC_DEL.1	The Delivery document describes the delivery procedures for the TOE to include the procedure on how to download certain components of the TOE from the Cisco website and how certain components of the TOE are physically delivered to the user. The delivery procedure detail how the end-user may determine if they have the TOE and if the integrity of the TOE has been maintained. Further, the delivery documentation describes how to acquire the proper license keys to use the TOE components.
ATE_COV.1 ATE_FUN.1	The Test document(s) consist of a test plan describes the test configuration, the approach to testing, and how the subsystems/modules and TSFI (TOE security function interfaces) has been tested against its functional specification and design as described in the TOE design and the security architecture description. The test document(s) also include the test cases/procedures that show the test steps and expected results, specify the actions and parameters that were applied to the interfaces, as well as how the expected results should be verified and what they are. Actual results are also included in the set of Test documents.
ATE_IND.2	Cisco will provide the TOE for testing.
AVA_VAN.2	Cisco will provide the TOE for testing.

6. TOE Summary Specification

6.1 TOE Security Functional Requirement Measures

The table below identifies and describes how the Security Functional Requirements identified above are met by the TOE.

Table 15 How TOE SFRs Measures

TOE SFRs	How the SFR is Met																						
FAU_GEN.1	Auditing is on by default at TOE startup and cannot be turned off A record is generated when the TOE starts and when the TOE is shutdown, thus indicating the starting and stopping of auditing.																						
FAU_GEN.2	<p>Each auditable event, the recorded information includes the user that triggered the event, the outcome or result of the event and when the event occurred.</p> <p>The user that triggered the event could be a human user where the user identity or related session ID would be included in the audit record. For an IT entity or device, the IP address, MAC address, host name, or other configured identification is presented.</p> <p>The auditable events include:</p> <table border="1" data-bbox="431 909 1422 1871"> <thead> <tr> <th data-bbox="431 909 773 982">Auditable Events</th> <th data-bbox="777 909 1118 982">Rationale</th> <th data-bbox="1123 909 1422 982">Additional Audit Record Contents</th> </tr> </thead> <tbody> <tr> <td data-bbox="431 982 773 1056">FIA_UAU.2 - All use of the authentication mechanism.</td> <td data-bbox="777 982 1118 1056" rowspan="2">All login attempts (Successful and failed) to the TOE HX Connect GUI and HX CLI are logged. The record is logged to the local audit storage</td> <td data-bbox="1123 982 1422 1056" rowspan="2">Provided user identity, origin of the attempt (e.g., IP address).</td> </tr> <tr> <td data-bbox="431 1056 773 1150">FIA_UID.2 - All use of the identification mechanism.</td> </tr> <tr> <td data-bbox="431 1150 773 1308">FMT_MSA.3 - Modifications of the default setting of permissive or restrictive rules and all modifications of the initial values of security attributes</td> <td data-bbox="777 1150 1118 1308">Successful and failed attempts to change the configuration data are logged in the local audit log</td> <td data-bbox="1123 1150 1422 1308">None</td> </tr> <tr> <td data-bbox="431 1308 773 1444">FMT_MTD.1 - All modifications to the values of TSF data</td> <td data-bbox="777 1308 1118 1444">Successful and failed attempts to change the configuration data are logged in the local audit log</td> <td data-bbox="1123 1308 1422 1444">The identity of the authorized administrator performing the operation.</td> </tr> <tr> <td data-bbox="431 1444 773 1581">FMT_SMF.1 - Use of the management functions</td> <td data-bbox="777 1444 1118 1581">Successful and failed attempts to change the configuration data are logged in the local audit log</td> <td data-bbox="1123 1444 1422 1581">The identity of the authorized administrator performing the operation.</td> </tr> <tr> <td data-bbox="431 1581 773 1654">FPT_FLS.1 – Failure with a preservation of secure state</td> <td data-bbox="777 1581 1118 1654">Failure of the TSF</td> <td data-bbox="1123 1581 1422 1654">None</td> </tr> <tr> <td data-bbox="431 1654 773 1871">FPT_STM.1 - Changes to the time</td> <td data-bbox="777 1654 1118 1871">Successful and failed attempts to change the time zone and any time-related parameters including NTP server configuration are logged in the local audit log. Manual setting of the clock can only be performed via the CLI</td> <td data-bbox="1123 1654 1422 1871">The identity of the authorized administrator performing the operation.</td> </tr> </tbody> </table>	Auditable Events	Rationale	Additional Audit Record Contents	FIA_UAU.2 - All use of the authentication mechanism.	All login attempts (Successful and failed) to the TOE HX Connect GUI and HX CLI are logged. The record is logged to the local audit storage	Provided user identity, origin of the attempt (e.g., IP address).	FIA_UID.2 - All use of the identification mechanism.	FMT_MSA.3 - Modifications of the default setting of permissive or restrictive rules and all modifications of the initial values of security attributes	Successful and failed attempts to change the configuration data are logged in the local audit log	None	FMT_MTD.1 - All modifications to the values of TSF data	Successful and failed attempts to change the configuration data are logged in the local audit log	The identity of the authorized administrator performing the operation.	FMT_SMF.1 - Use of the management functions	Successful and failed attempts to change the configuration data are logged in the local audit log	The identity of the authorized administrator performing the operation.	FPT_FLS.1 – Failure with a preservation of secure state	Failure of the TSF	None	FPT_STM.1 - Changes to the time	Successful and failed attempts to change the time zone and any time-related parameters including NTP server configuration are logged in the local audit log. Manual setting of the clock can only be performed via the CLI	The identity of the authorized administrator performing the operation.
Auditable Events	Rationale	Additional Audit Record Contents																					
FIA_UAU.2 - All use of the authentication mechanism.	All login attempts (Successful and failed) to the TOE HX Connect GUI and HX CLI are logged. The record is logged to the local audit storage	Provided user identity, origin of the attempt (e.g., IP address).																					
FIA_UID.2 - All use of the identification mechanism.																							
FMT_MSA.3 - Modifications of the default setting of permissive or restrictive rules and all modifications of the initial values of security attributes	Successful and failed attempts to change the configuration data are logged in the local audit log	None																					
FMT_MTD.1 - All modifications to the values of TSF data	Successful and failed attempts to change the configuration data are logged in the local audit log	The identity of the authorized administrator performing the operation.																					
FMT_SMF.1 - Use of the management functions	Successful and failed attempts to change the configuration data are logged in the local audit log	The identity of the authorized administrator performing the operation.																					
FPT_FLS.1 – Failure with a preservation of secure state	Failure of the TSF	None																					
FPT_STM.1 - Changes to the time	Successful and failed attempts to change the time zone and any time-related parameters including NTP server configuration are logged in the local audit log. Manual setting of the clock can only be performed via the CLI	The identity of the authorized administrator performing the operation.																					

TOE SFRs	How the SFR is Met		
	FRU_FLT.2 – Limited fault tolerance	Any failure detected by the TSF.	None
	FTA_SSL.3 - Termination of an interactive session by the session locking mechanism	Termination of the inactive session.	None
	FTP_TRP.1 - Attempts to use the trusted path functions.	Successful and failed attempts to use SSHv2 or HTTPS/TLSv1.2 are logged in the local audit log	Identification of the user associated with all trusted path invocations including failures, if available.
FAU_SAR.1	<p>The TOE provides the Authorized Administrator the ability to delete the audit records to manage audit log space.</p> <p>These audit records are available for review through the HX Connect GUI and the HX CLI interfaces. There are no other methods to view the audit records.</p> <p>The audit records include sufficient information for the Authorized Administrator to determine the event, the user who initiated the event, the date and time of the event and the outcome. Audit records are generated for all of the Converged Host clusters and datastores.</p>		
FAU_STG.1	<p>The audit records are stored in an internal file and this internal file cannot be altered.</p> <p>Using the HX Connect GUI webpages and the HXCLI commands, Task Viewer, the Authorized Administrator can view the audit records once they have been successfully identified and authenticated. The HX Connect GUI webpages and the HXCLI commands interface also provides the Authorized Administrator the capability to delete the audit logs to manage the audit log space.</p>		
FDP_ACC.2 and FDP_ACF.1	<p>The Converged Host spans three or more Cisco HyperFlex HX Series nodes to create a highly available Cluster and datastores. Each node includes a Cisco HyperFlex HX Data Platform controller that implements the distributed file system using internal flash-based SSD drives and high-capacity HDDs to store data.</p> <p>The TOE implements whitelist access controls of the Remote Host access to the Converged Host clusters and datastores. The whitelist is an IP table that includes the IP addresses of the Host VMs that have access to the HX nodes clusters and datastores. If the IP address is included on the whitelist and if there is sufficient storage capacity, access is granted otherwise access is denied.</p> <p>The Cisco HyperFlex HX Data Platform controller handles all read and write requests for volumes that the hypervisor accesses and thus mediates all I/O from the virtual machines. The data platform implements a log-structured file system that uses a caching layer in SSD drives to accelerate read requests and write responses, and a persistence layer implemented with HDDs.</p>		
FIA_ATD.1	<p>The TOE supports definition of Authorized Administrator by individual user IDs. For each Authorized Administrator, the TOE maintains the following attributes:</p> <ul style="list-style-type: none"> a) user identity b) password <p>Authorized Administrator are administrators that are granted access to specific resources and permission to perform specific tasks.</p>		
FIA_SOS.1	<p>To prevent users from choosing insecure passwords, the TOE prompts the user that the password should meet the following requirements:</p> <ul style="list-style-type: none"> • At least eight characters long • includes upper and lower case characters • Includes alpha numeric characters 		

TOE SFRs	How the SFR is Met
	<p>This requirement applies to the local password database and on the password selection functions provided by the TOE.</p>
<p>FIA_UID.2 and FIA_UAU.2</p>	<p>By default, the TOE uses the local database for identification and authentication.</p> <p>No access is allowed prior encountering an authentication prompt and then being successfully identified and authenticated.</p> <p>Only after authentication, is the Authorized Administrator able to perform any actions.</p>
<p>FIA_UAU.7</p>	<p>When a user enters their password for remote session authentication, the TOE does not echo any characters as they are entered.</p>
<p>FMT_MSA.1</p>	<p>The TOE provides the Authorized Administrator the ability to modify the default security attribute values used for resource and access control.</p>
<p>FMT_MSA.3</p>	<p>The TOE provides restrictive default values for resources and access control.</p> <p>No access is allowed to the protected resources unless the attributes match, and resources are available.</p>
<p>FMT_MTD.1</p>	<p>The TOE provides the ability for Authorized Administrators to access TOE data, such as audit data, configuration data, security attributes, session thresholds and updates.</p>
<p>FMT_SMF.1</p>	<p>The TOE provides all the capabilities necessary to securely manage the TOE. The Authorized Administrator can connect to the TOE using the HX Connect GUI webpages using HTTPS/TLSv1.2 and the HX CLI commands using SSHv2 to perform these functions.</p> <p>The specific management capabilities available from the TOE include:</p> <ul style="list-style-type: none"> • Administer the TOE remotely • Manage access control attributes • Manage Authorized Administrator’s security attributes • Review audit record logs • Configure and manage the system time
<p>FMT_SMR.1</p>	<p>The TOE maintains Authorized Administrator role to administer the TOE remotely. The TOE maintains Authorized Administrator role to administer the TOE remotely. During the installation of the TOE Authorized Administrator user is created. Additional Authorized Administrator users may be created; each must be assigned a unique user name and password.</p> <p>All users of the TOE are considered Authorized Administrators. It is assumed all administrators are trusted, trained, knowledgeable, and will follow the guidance to ensure the TOE is properly monitored and operated in a secure manner.</p> <p>The Authorized Administrator can connect to the TOE using the HX Connect GUI webpages using HTTPS/TLSv1.2 and the HXCLI commands using SSHv2 to secure the connection.</p>
<p>FPT_FLS.1</p>	<p>The TOE provides the capability to take a snapshot in time of the HX Data Platform VMs. Snapshots help facilitate backup and remote-replication operations where the organization requires an ‘always-on’ data availability. The snapshot is a reproduction of the VM that includes the state of the data on all VM disks and the VM poser state ((on, off or suspended) at the time, the snapshot is taken. The snapshot is saved so the Authorized Administrator has the option to revert to the saved state.</p>

TOE SFRs	How the SFR is Met
	<p>For each VM in your storage cluster, you can schedule hourly, daily, or weekly snapshots. You can schedule snapshots to adjust to the organization's backup requirements. For example, you can retain more frequent snapshots of critical data so if there is a failure, you can restore the most recent snapshots. For example, the initial HyperFlex native snapshot with the virtual machine powered off. This creates what is called the Sentinel snapshot. The Sentinel snapshot becomes a base snapshot that all future snapshots are added. Snapshots can be scheduled to occur at specific days and times.</p> <p>If a disk failure happens, the TOE cluster states turn to 'unhealthy' and a rebalancing job is triggered to return the system to the specified replication factor, replicating the missing data on the disk from the remaining copies and once the job completes the cluster returns to a healthy state.</p>
FPT_STM.1	<p>The TOE provides a source of date and time information used in audit event timestamps. The TOE is configured to use NTP to synchronize the TOE's clock with an external time source. This date and time is used as the timestamp that is applied to audit records generated by the TOE and to track inactivity of administrative sessions. The timestamps are synchronized across the Cisco HyperFlex HX Series Nodes, the storage controller VMs (storage controller) and ESXi hosts (Hypervisor).</p>
FRU_FLT.2	<p>The TOEs High Availability (HA) feature ensures that the storage cluster maintains at least two copies of all data during normal operation with three or more fully functional nodes.</p> <p>If one or more nodes in the storage cluster fail, the state of the storage cluster is affected, however data is preserved. If more than one node and/or disk fail, it is called a simultaneous failure. The number of nodes in the storage cluster, the Data Replication Factor and Access Policy settings determine the state of the storage cluster that results from node failures. The strict setting helps protect the data in event of simultaneous failures.</p> <p>Data Replication Factor provides the option to set the number of redundant replicas of data across the storage cluster. The choices are:</p> <ul style="list-style-type: none"> • Data Replication Factor 3 — Keep three redundant replicas of the data. This consumes more storage resources and ensures the maximum protection for your data in the event of node or disk failure. <ul style="list-style-type: none"> ○ Data Replication Factor 3 is the recommended option. • Data Replication Factor 2 — Keep two redundant replicas of the data. This consumes fewer storage resources but reduces your data protection in the event of node or disk failure.
FTA_SSL.3	<p>When a session is inactive (i.e. no session input) for more than the Authorized Administrator configured time, the TOE will terminate the session and no further activity is allowed, requiring the Authorized Administrator to log in (be successfully identified and authenticated) again to establish a new session.</p> <p>The timeout value is configurable. The default setting is 120 minutes of idle time.</p>
FTP_TRP.1	<p>The TOE ensures the communication path and the remote administer interfaces is protected and distinct from other communications paths. The HX Connect GUI uses HTTPS/TLSv1.2 and HX CLI uses SSHv2.</p>

6.2 TOE Bypass and interference/logical tampering Protection Measures

The TOE consists of a hardware platform in which all operations in the TOE scope are protected from interference and tampering by untrusted subjects. All administration and configuration operations are performed within the physical boundary of the TOE. In addition, all security policy enforcement functions must be invoked and succeed prior to functions proceeding.

The TOE has been designed so that all locally maintained TSF data can only be manipulated via the HX Connect GUI and HX CLI interfaces. There are no undocumented interfaces for managing the product.

All sub-components included in the TOE rely on the main chassis for power and memory while the TOE software provides the management functions and control. To access any portion of the TOE, the Identification and Authentication mechanisms of the TOE must be invoked and succeed.

No processes outside of the TOE are allowed direct access to any TOE memory. The TOE only accepts traffic through legitimate TOE interfaces. Specifically, processes outside the TOE are not able to execute code on the TOE. None of these interfaces provides any access to internal TOE resources.

Only the Authorized Administrator has access to the TOE security functions.

There are no unmediated traffic flows into or out of the TOE or unauthenticated access, thus providing a distinct protected domain for the TOE that is logically protected from interference and is not bypassable.

7. Rationale

This section describes the rationale for the Security Objectives and Security Functional Requirements as defined within this Security Target.

7.1 Rationale for TOE Security Objectives

Table 16 Threats & IT Security Objectives Mapping

	T.ACCOUNTABILITY	T.NOAUTH	T.RESOURCE_AVAILABILITY
O.ACCESS_CONTROL		X	
O.ADMIN		X	X
O.AUDIT_GEN	X		
O.AVAILABILITY			X
O.AUDIT_VIEW	X		
O. DATA		X	
O.IDAUTH		X	
O.SELFPRO		X	
O.TIME	X		

Table 17 TOE Threat/Policy/Objective Rationale

Threat / Policy	Rationale for Coverage
T.ACCOUNTABILITY	An authorized administrative is not held accountable for their actions on the TOE because the audit records are not generated, do not include the required data, including properly sequenced through application of correct timestamps or reviewed. The O.AUDIT_GEN objective mitigates the threat by requiring the TOE generate audit records for events performed on the TOE. The O.AUDIT_VIEW requires the TOE to provide the authorized administrator with the capability to view audit data. The O.TIME objective mitigates this threat by providing the accurate time to the TOE for use in the audit records O.AUDIT_GEN.
T.NOAUTH	O.SELFPRO objective ensures that an unauthorized person (attacker) that may attempt to bypass the security of the TOE to access data and use security functions and/or non-security functions provided by the TOE to disrupt operations of the TOE is not successful. The O.DATA objective protects the configuration and user data from unauthorized disclosure. The O.IDAUTH objective requires the administrative user to enter a unique identifier and authentication credentials before management access is granted. The O.ADMIN objective ensures the authorized administrator has access to the TOE to configure access controls and the O.ACCESS_CONTROL objective restricts access to the TOE management functions to the Authorized Administrator.
T.RESOURCE_AVAILABILITY	The TOE user data could become corrupted or unavailable due to hardware or system operation failures. The O.AVAILABILITY objective to maintain a secure state and to protect user data from loss or corruption due to hardware or system operation failures. The O.ADMIN ensures the administrator has the capabilities to ensure proper configuration for maintaining a secure state and resource availability.

7.2 Rationale for TOE Security Objectives for the Environment

The security requirements are derived according to the general model presented in Part 1 of the Common Criteria. Specifically, the tables below illustrate the mapping between the security requirements and the security objectives and the relationship between the threats, policies, and IT security objectives. The functional and assurance requirements presented in this Security Target are mutually supportive and their combination meets the stated security objectives.

Table 18 Threats & IT Security Objectives Mappings for the Environment

	A.ADMIN	A.CONNECTIONS	A.LOCATE
OE.ADMIN	X		
OE.CONNECTION		X	
OE_SC.CONNECTION		X	
OE.LOCATE			X

Table 19 Assumptions/Threats/Objectives Rationale

Assumptions	Rationale for Coverage of Environmental Objectives
A.ADMIN	All Authorized Administrator are assumed not evil, will follow the administrative guidance and will not disrupt the operation of the TOE intentionally. The OE.ADMIN objective ensures that Authorized Administrator are not careless, willfully negligent, or hostile, and will follow and abide by the instructions provided by the TOE documentation, including the administrator guidance; however, they are capable of error.
A.CONNECTIONS	The operational environment in which the TOE is installed will allow the users of the TOE to access the stored information. The OE.CONNECTION objective ensures the operational environment provides a protected network to prevent unauthorized access to the TOE. When the TOE is deployed in the Stretched Cluster configuration, the OE_SC.CONNECTION objective ensures the connection between the two sites is secured using the Private Fiber to prevent unauthorized access to the TOE.
A.LOCATE	The processing resources of the TOE and those services provided by the operational environment will be located within controlled access facilities, which will prevent unauthorized physical access. The OE.LOCATE objective ensures the processing resources of the TOE and those services provided by the operational environment will be located within controlled access facilities, which will prevent unauthorized physical access.

7.3 Rationale for requirements /TOE Objectives

The security requirements are derived according to the general model presented in Part 1 of the Common Criteria. Specifically, the tables below illustrate the mapping between the security requirements and the security objectives and the relationship between the threats, and IT security objectives.

Table 20 Security Objective to Security Requirements Mappings

	O.ACCESS_CONTROLL	O.ADMIN	O.AUDIT_GEN	O.AVAILABILITY	O.AUDIT_VIEW	O.DATA	O.IDAUTH	O.SELPRO	O.TIME
FAU_GEN.1	X		X						X
FAU_GEN.2	X		X						
FAU_SAR.1					X				
FAU_STG.1	X								
FDP_ACC.2						X		X	
FDP_ACF.1						X		X	
FIA_ATD.1	X	X					X		
FIA_SOS.1							X		
FIA_UAU.2						X	X	X	
FIA_UAU.7							X		
FIA_UID.2						X	X	X	
FMT_MSA.1	X	X						X	
FMT_MSA.3	X	X						X	

	O.ACCESS_CONTROL	O.ADMIN	O.AUDIT_GEN	O.AVAILABILITY	O.AUDIT_VIEW	O.DATA	O.IDAUTH	O.SELPRO	O.TIME
FMT_MTD.1	X	X							
FMT_SMF.1	X	X				X			
FMT_SMR.1	X	X							
FPT_FLS.1				X					
FPT_STM.1			X						X
FRU_FLT.2				X					
FTA_SSL.3	X						X	X	
FTP_TRP.1		X					X	X	

Table 21 Objectives to Requirements Rationale

Objective	Rationale
O.ACCESS_CONTROL	The TOE will restrict access to the TOE Management functions to the Authorized Administrator. The TOE is required to provide the ability to restrict the use of TOE management/administration/security functions to Authorized Administrator of the TOE. The Authorized Administrator performs these functions on the TOE. Only Authorized Administrator of the TOE may modify TSF data [FMT_MTD.1] and delete audit data stored locally on the TOE [FAU_STG.1]. The TOE must be able to recognize the administrative privilege level that exists for the TOE [FIA_ATD.1, FMT_SMR.1]. The TOE must allow the Authorized Administrator to specify alternate initial values when an object is created [FMT_MSA.1, FMT_MSA.3]. The TOE ensures that all user actions resulting in the access to TOE security functions and configuration data

Objective	Rationale
	are controlled [FMT_SMF.1] and audited [FAU_GEN.1, FAU_GEN.2]. The SFR FTA_SSL.3 also meets this objective by terminating a session due to meeting/exceeding the inactivity time limit.
O.ADMIN	The TOE will provide administrative functions to isolate administrative actions by configuring and assigning Authorized Administrator accounts [FIA_ATD.1, FMT_SMR.1], thus controlling access to the TSF data and configuration [FMT_MSA.1, FMT_MSA.3, FMT_MTD.1, FMT_SMF.1, FMT_SMR.1]. The TOE will also make the administrative functions available remotely via SSHv2 and HTTPS/TLSv1.2 [FTP_TRP.1].
O.AUDIT_GEN	The TOE will generate audit records which will include the time [FPT_STM.1] that the event occurred and if applicable, the identity of the user performing the event [FAU_GEN.2]. All TOE security relevant events are auditable and will include the required information to identify when the event occurred, the event, who performed the action, and the success or failure of the event [FAU_GEN.1 and FAU_GEN.2]. Timestamps associated with the audit record must be reliable [FPT_STM.1].
O.AVAILABILITY	The TOE will provide mechanisms to maintain a secure state and mitigate against user data disclosure, loss or corruption due to hardware or system operation failures [FPT_FLS.1 and FRU_FTL.2].
O.AUDIT_VIEW	The TOE will provide the Authorized Administrator the capability to review Audit data via the HX Connect GUI and HX CLI interfaces. Security relevant events are available for review by Authorized Administrator [FAU_SAR.1].
O.DATA	<p>The TOE is required to protect the TSF data from unauthorized access therefore each Authorized Administrator must be identified and authenticated prior to gaining access [FIA_UAU.2 and FIA_UID.2]. The TOE ensures that access to TOE configuration settings (HX Connect GUI webpages and HX CLI commands), data and resources is done in accordance with the management functions [FMT_SMF.1].</p> <p>The TOE is also required to restrict access to the HX clusters and datastores [FDP_ACC.2, FDP_ACF.1].</p>
O.IDAUTH	The TOE must uniquely identify and authenticate the claimed identity of all administrative users before granting management access. The Authorized Administrators' password must meet formatting requirements to prevent the use of weak credentials [FIA_SOS.1]. The TOE is required to store user security attributes to enforce the authentication policy of the TOE and to associate security attributes with users [FIA_ATD.1]. Users authorized to access the TOE must be defined using an identification and authentication process and all users must be successfully identified and authenticated [FIA_UID.2 and FIA_UAU.2]. The password is obscured when entered [FIA_UAU.7]. If the period of inactivity has been exceeded, the user is required to re-authenticate to re-establish the session [FTA_SSL.3].

Objective	Rationale
O.SELFPRO	<p>The TOE must protect itself against attempts by unauthorized users to bypass, deactivate, or tamper with TOE security functions. [FDP_ACC.2, FDP_ACF.1, FIA_UID.2 and FIA_UAU.2] supports this objective by ensuring access to the resources is controlled and only Authorized Administrator can manage the resources [FMT_MSA.1 and FMT_MSA.3]. The [FTP_TRP.1] ensures the communication path and the remote administer interfaces is protected and distinct from other communications paths. The SFR [FTA_SSL.3] also meet this objective by terminating a session due to meeting/exceeding the inactivity time limit thus ensuring the session does not remain active and subject to attack.</p>
O.TIME	<p>The TSF will provide a reliable time stamp for its own use. The TOE is required to provide reliable timestamps for use with the audit record [FAU_GEN.1, FPT_STM.1]. The TOE is configured to synchronize its clock with an NTP server.</p>

8. Annex A: References

The documentation listed below was used to prepare this ST

Table 22 References

Identifier	Description
[CC_PART1]	<i>Common Criteria for Information Technology Security Evaluation – Part 1: Introduction and general model</i> , dated September 2012, version 3.1, Revision 5, CCMB-2017-04-001
[CC_PART2]	<i>Common Criteria for Information Technology Security Evaluation – Part 2: Security functional components</i> , dated September 2012, version 3.1, Revision 5, CCMB-2017-04-002
[CC_PART3]	<i>Common Criteria for Information Technology Security Evaluation – Part 3: Security assurance components</i> , dated September 2012, version 3.1, Revision 5, CCMB-2017-04-003
[CEM]	<i>Common Methodology for Information Technology Security Evaluation – Evaluation Methodology</i> , dated September 2012, version 3.1, Revision 5, CCMB-2017-04-004

9. Annex B: Acronyms

The following acronyms and terms are common and may be used in this Security Target.

Table 23 Acronyms

Acronym/Term	Definition
AAA	Administration, Authorization, and Accounting
ACL	Access Control Lists
AES	Advanced Encryption Standards
AES-CCM	AES Counter with CBC-MAC
AP	Access Point
API	Application Programming Interface
CC	Common Criteria
CEM	Common Evaluation Methodology
CIMC	Cisco Integrated Management Controller
CIM-XML	Common Information Model XML
CLI	Command Line Interface
CM	Configuration Management
EAL	Evaluation Assurance Level
FC	Fibre Channel
GUI	Graphical User Interface
HDD	Hard-disk drives
HTTPS	Hyper-Text Transport Protocol Secure
HX	HyperFlex
IP	Internet Protocol
OS	Operating System
SAR	Security Assurance Requirement
SFP	Security Functional Policy
SFR	Security Functional Requirement
SM	Service Module
SSD	Solid-state disk

SSL	Secure Socket Layer
ST	Security Target
TCP	Transport Control Protocol
TCP/IP	Transmission Control Protocol/Internet Protocol
TLS	Transport Layer Security
TOE	Target of Evaluation
TSC	TSF Scope of Control
TSF	TOE Security Function
TSP	TOE Security Policy
UCS	[Cisco] Unified Computing System
UCSM	UCS Manager
UDP	User datagram protocol
VIB	VMware ESXi vSphere Installation Bundles
VLAN	Virtual Local Area Network
VM	Virtual Machine, a virtualized guest operating system installed to a hypervisor.
VMM	Virtual Machine Manager, a hypervisor.
VSAN	Virtual Storage Area Network
XML	Extensible Markup Language
XML API	The UCS Manager XML API is a programmatic interface for managing UCS via CLI.

10. Annex C – Terminology

The following terms are common and may be used in this Security Target.

Table 24 Terms

Term	Definition
Cluster	A collection of hosts that are interconnected for the purpose of improving reliability, availability, serviceability, load balancing and performance. In this document, cluster implies the storage cluster, unless otherwise stated.
Cluster Access Policy	HX Data Platform (TOE) configurable feature that specifies storage cluster data management when the nodes or disks fail in the storage cluster. For example, when the storage cluster changes to read-only mode to protect data.
Datastore	A logical container, similar to a file system on a logical volume. Datastores are where the host places virtual disk files and other VM files. Datastores hide the specifics of physical storage devices and provide a uniform model for storing VM files.
Extended Cluster	The addition of Cisco UCS rack-mount servers and/or Cisco UCS 5108 Blade chassis, which house Cisco UCS blade servers that allows for additional compute resources in an extended cluster design.
Hyperconvergence	Turning standard servers of choice into a single pool of compute and storage resources.
HyperFlex HX Data Platform Controller (also referenced as controller VM)	The HyperFlex HX Data Platform controller resides on each node and implements the distributed file system. The controller VM runs in user space within a virtual machine, intercepts, and handles all I/O from guest virtual machines (VM).
IO Visor	This [TOE] VIB provides a network file system (NFS) mount point so that the VMware ESXi hypervisors can access the HyperFlex HX Data Platform virtual disk drives that are attached to individual virtual machines. From the hypervisor's perspective, it is simply attached to a network file system.
Layer 2 (L2)	Layer 2, also known as the Data Link Layer, is the second level in the seven-layer OSI reference model for network protocol design. Layer 2 is equivalent to the link layer (the lowest layer) in the TCP/IP network model. Layer2 is the network layer used to transfer data between adjacent network nodes in a wide area network or between nodes on the same local area network.
Layer 3 (L3)	<p>Layer 3 refers to the third layer of the Open Systems Interconnection (OSI) Model, which is the network layer. Layer 3 is responsible for all packet forwarding between intermediate routers, as opposed to Layer 2 (the data link layer), which is responsible for media access control and flow control, as well as error checking of Layer 1 processes.</p> <p>Traditional switching operates at layer 2 of the OSI model, where packets are sent to a specific switch port based on destination MAC addresses. Routing operates at layer 3, where packets are sent to a specific next-hop IP address, based on destination IP address. Devices in the same layer 2 segment do not need routing to reach local peers. What is needed however is the destination MAC address which can be resolved through the Address Resolution Protocol (ARP)</p>

Private Fiber	<p>The term Private Fiber’ encompasses the leasing ‘private’ fiber optic cables from network providers. A client leases or purchases unused strands of ‘private’ fiber optic cable to create their own privately-operated optical fiber network rather than simply leasing bandwidth.</p> <p>The Private Fiber network is separate from the public (main) network and is controlled by the client and not the network provider.</p> <p>Private Fiber networks can be set up in a variety of ways, including Private Fiber rings, point to point or point-to-multipoint configurations. With Private Fiber, a client can expect higher levels of performance, a highly secure network and superfast speeds.</p>
Split Brain	<p>In the Stretched Cluster (SC) deployment this is where the two sides of the system lose communication with one another, but the system has not actually failed. In this circumstance, if either side has no secondary method besides network communication for determining if the other side has actually failed, in the interest of maximizing system availability it will decide that it is now the authoritative or active half. As such, both sides would make the same determination, therefore both sides would think they are active and in charge of the overall system, hence the term “split brain”.</p>
Standard Cluster	<p>Composed of a pair of Cisco UCS Fabric Interconnects along with up to thirty-two HX-Series rack-mount servers per cluster.</p>
Storage Cluster	<p>The storage cluster contains the converged nodes and their associated storage that the HX Data Platform (TOE) manages. This storage cluster can also include compute nodes, that do not include storage, and that the HX Data Platform (TOE) monitors.</p>
Stretched Cluster (SC)	<p>Stretched Cluster (SC) allow nodes to be evenly split between two physical locations, keeping a duplicate copy of all data in both locations, thereby providing protection in case of an entire site failure.</p> <p>The connection between the two sites is secured using the Private Fiber for point-to-point network configuration.</p>
Users	<p>The users of the TOE are the processes and applications on the VMs that are on the TOE that access the storage clusters and datastores which are provided by the TOE.</p>
Virtual Local Area Network (VLAN)	<p>The VLANs enable efficient traffic separation, provide better bandwidth utilization, and alleviate scaling issues by logically segmenting the physical local-area network (LAN) infrastructure into different subnets so that VLAN packets are presented to interfaces within the same VLAN. The most important requirement of VLANs is the ability to identify the origination point for packets with a VLAN tag to ensure packets can only travel to interfaces for which they are authorized, thus creating Layer 2 (data link) implementations of subnets.</p>
Virtual Machines (VMs)	<p>The virtual machines are the virtual servers on the TOE that access the storage clusters and datastores, which are provided by the TOE.</p>
vMotion	<p>Enables the live migration of running virtual machines from one physical server to another with zero downtime, continuous service availability and complete transaction integrity. It is transparent to users.</p>
VMware vCenter	<p>In the evaluated configuration, VMware vCenter functions as a remote authentication server providing the Authorized Administrator the capability of creating additional administrator accounts and storing the credentials.</p>
VMware vStorage API for Array Integration (VAAI)	<p>This storage offload [TOE] API allows vSphere to request advanced file system operations such as snapshots and cloning. The controller causes these operations to occur through manipulation of metadata rather than actual data copying, providing rapid response, and thus rapid deployment of new application environments</p>

Whitelist	A whitelist may consist of a list of users, applications or processes that are viewed with approval or being provided a particular privilege. Entities on the whitelist will be approved, recognized and/or accepted. For the TOE, the whitelist consists of IP addresses of cluster members (Nodes) that have access to the HyperFlex HX Data storage clusters and datastores that are controlled and enforced by the TOE.
Witness VM	A Witness VM is part of the Stretched Cluster (SC) to avoid 'Split Brain' scenario, a third system (Witness VM) is required to break this tie or provide additional information and decision-making logic to prevent simultaneous takeover by the two sides of the Stretched Cluster.
Virtual Local Area Network (VLAN)	VLAN VLANs enable efficient traffic separation, provide better bandwidth utilization, and alleviate scaling issues by logically segmenting the physical local-area network (LAN) infrastructure into different subnets so that VLAN packets are presented to interfaces within the same VLAN. The most important requirement of VLANs is the ability to identify the origination point for packets with a VLAN tag to ensure packets can only travel to interfaces for which they are authorized.

11. Annex D: Obtaining Documentation and Submitting a Service Request

For information on obtaining documentation, using the Cisco Bug Search Tool (BST), submitting a service request, and gathering additional information, see [What's New in Cisco Product Documentation](#).

To receive new and revised Cisco technical content directly to your desktop, you can subscribe to the [What's New in Cisco Product Documentation RSS feed](#). The RSS feeds are a free service.

12. Contacting Cisco

Cisco has more than 200 offices worldwide. Addresses, phone numbers, and fax numbers are listed on the Cisco website at www.cisco.com/go/offices.